


MOUNTING AND INSTRUCTION MANUAL

DTS 4148.grandmaster

Network – Time Server and Master Clock



Certification of the Producer

STANDARDS

The DTS 4148.grandmaster was developed and produced in accordance with the EU Guidelines:

2014 / 30 / EU	EMC
2014 / 35 / EU	LVD
2008 / 57 / EU	Railway
2011 / 65 / EU	RoHS
1907 / 2006	REACH

C€ F©







CH-6857

References to the Instruction Manual

- 1. The information in this Instruction Manual can be changed at any time without notice. The current version is available for download on www.mobatime.com.
- 2. The device software is continuously being optimized and supplemented with new options. For this reason, the newest software version can be obtained from the Mobatime website.
- 3. This Instruction Manual has been composed with the utmost care, in order to explain all details in respect of the operation of the product. Should you, nevertheless, have questions or discover errors in this Manual, please contact us.
- 4. We do not answer for direct or indirect damages, which could occur, when using this Manual.
- 5. Please read the instructions carefully and only start setting-up the product, after you have correctly understood all the information for the installation and operation.
- 6. The installation must only be carried out by skilled staff.
- 7. It is prohibited to reproduce, to store in a computer system or to transfer this publication in a way or another, even part of it. The copyright remains with all the rights with BÜRK MOBATIME GmbH, D-78026 VS-Schwenningen and MOSER-BAER AG CH 3454 Sumiswald / SWITZERLAND.

Overview

1	Safety	
2	Maintenance	8
3	General Information: Introduction	9
4	Displays	
5	Installation	15
6	Operation	
7	Updates	
	Time administration	
9	SNMP	71
10	Power supply alternatives	75

APPENDIX

А	Connection diagrams	76
В	Time zone table	
С	Alarm list	85
D	Troubleshooting	87
Е	Serial Telegrams	
F	Copyright Notice	
G	Parameters	95
Н	Technical data	
I	Index	
J	Connection table (to fill in)	105

Table of contents

1	Safety6	
	1.1 Safety instructions	
	1.2 Symbols and Signal Words used in this	
	Instruction Manual6	
	1.3 Intended Use6	
	1.4 Observe operating safety!	
	1.5 Consider the installation site!7	
	1.6 Please observe the electromagnetic	
	compatibility!7 1.7 Network security7	
_		
2	Maintenance8	
	2.1 Troubleshooting: Repairs	
	2.2 Cleaning	
	2.3 Disposing8	
3	General Information: Introduction	
	3.1 Scope of Delivery	
	3.2 Technical Data	
	3.3 Device Description in this Manual	
	3.4 Introduction	
	3.5 Device types10	
	3.6 DTS Distributed Time System10	
	3.7 MOBA-NMS - Network Management System 10	
	3.7.1 Overview of the main functions	
	3.7.2 Device management12	
4	Displays 13	
	4.1 LED displays front side13	
	4.2 LED indication back side	
	4.3 Display14	
5	Installation	
5		
	5.1 Connections	
	5.2 Boot procedure of the DTS 4148.grandmaster15 5.3 Initial configuration15	
	5.4 Firmware	
	5.5 Basic settings (factory settings)15	
6	Operation	
0	-	
	6.1 General	
	6.1.1 Telnet	
	6.1.3 Menu structure	
	6.2 MOBA-NMS operation18	
	6.3 Main menu	
	6.4 Status menu20	
	6.4.1 Time information and status	
	6.4.2 Time source information	
	6.5 Configuration menu24 6.5.1 Lines	
	6.5.2 DCF – output	
	6.5.3 DCF / Pulse / Frequency output	
	6.5.4 Serial interface	
	6.5.5 IRIG / AFNOR / DCF-FSK Output	
	6.5.6 NTP slave clocks / time zone server	
	6.5.8 Time source	
	6.5.9 Time adjustment / Time-keeping	
	6.5.10 Redundant operation 34	
	6.5.11 NTP server	
	6.5.12 Manual time set / Leap second	
	6.5.13 PTP Server 40	
	6.5.13 PTP Server	
	6.5.14 Alarms	
	6.5.14 Alarms 41 6.5.15 Alarm relay 42 6.5.16 Alarm mask 42	
	6.5.14 Alarms 41 6.5.15 Alarm relay 42 6.5.16 Alarm mask 42 6.5.17 E-mail 43	
	6.5.14 Alarms 41 6.5.15 Alarm relay 42 6.5.16 Alarm mask 42 6.5.17 E-mail 43 6.5.18 SNMP traps 45	
	6.5.14 Alarms 41 6.5.15 Alarm relay 42 6.5.16 Alarm mask 42 6.5.17 E-mail 43	

 7 Updates	57 57 58 58 59 50 50 51
 7.2 Updating images with FTP	57 58 58 59 50 50 51
 7.2 Updating images with FTP	57 58 58 59 50 50 51
 7.3 Updating applications or configurations with FTP	i8 i8 i9 i0 i0
 7.4 Updating images via USB	i8 i9 i0 i0
 7.5 Updating applications or configurations via USB	59 50 50
USB5 7.6 FTP connection	0 0 1
7.6 FTP connection	50 51
	51
7.7 SFTP connection	
7.8 SCP connection	
7.9 Save Configuration externally	
4148.grandmaster	2
8 Time administration63	
8.1 Concept of time administration	
8.2 Time acceptance	4
8.3 Time acceptance from an external source	
(DCF or GPS)6	4
8.4 Time acceptance from external AFNOR-A/C,	Ē
IRIG-B12x source6 8.5 Time acceptance from NTP6	5
8.6 NTP as backup	
8.7 Time server	
8.8 Time accuracy, time-keeping6	
8.9 Leap second	
8.10 NTP Authentication	
8.10.1 NTP symmetric keys6 8.10.2 NTP Autokey	
8.11 PTP	
8.12 Redundant operation of 2 DTS	
4148.grandmasters6	9
9 SNMP7	1
9.1 General7	'1
9.2 Device configuration with SNMP7	
9.3 DTS subagent SNMP notification	
9.3.1 Startup [dts4148StartUp]7 9.3.2 Shutdown [dts4148Shutdown]7	
9.3.3 Status changed [dts4148StatusChanged]	
9.3.4 Configuration changed	
[dts4148ConfigChanged]7 9.3.5 Alive Notification [dts4148Alive]7	
9.3.6 Alarm Notification [dts4146Alarm]7	′3 ′⊿
10 Power supply alternatives	74

APPENDIX

A	A.1 A.2 A.3	Connection diagrams76Front connections76Connections (rear view)77Plug-in spring terminals79
	A.4	Connection GPS 4500, DCF 450 or GNSS 300079
	A.5	IRIG-B00x Digital Output TTL connection79
В		Time zone table 80
С		Alarm list
D		Troubleshooting
Е		Serial Telegrams
	E.1 E.2	General89 Syntax of the telegram configuration file90
F		Copyright Notice
G		Parameters
Н		Technical data 100
Ι		Index 103
J		Connection table (to fill in) 105

1 Safety

1.1 Safety instructions



Read this chapter and the entire instruction manual carefully and follow all instructions listed. This is your assurance for dependable operations and a long life of the device.

Keep this instruction manual in a safe place to have it handy every time you need it.

1.2 Symbols and Signal Words used in this Instruction Manual

	Danger! Please observe this safety message to avoid electrical shock! There is danger to life!
	Warning! Please observe this safety message to avoid bodily harm and injuries!
	Caution! Please observe this safety message to avoid damages to property and devices!
İ	Notice! Additional information for the use of the device.

1.3 Intended Use

The **DTS 4148.grandmaster** is a time server for the use in network environments. It can be synchronized from NTP and be used as NTP server. In addition, it can read the time from DCF or GPS (e.g. from GPS 4500).

It can operate as master clock for a self-setting IRIG clock line. The DTS 4148 has 1 such line.

For additional functions, see the device descriptions in chapter 3.

The device is designed for 19" racks and intended to be installed in a 19" cabinet. Operate the device only in installed condition and with all connectors plugged in.

Use this product only as stated in this instruction manual. Any other use is considered improper use.



1.4 Observe operating safety!

- Never open the housing of the device! This could cause an electric short or even a fire, which would damage your device. Do not modify your device!
- The device is not intended for use by persons (including children) with limited physical, sensory, or mental capacities or a lack of experience and/or knowledge.
- Keep packaging such as plastic films away from children. There is the risk of suffocation if misused.



Consider the installation site!

- To avoid any operating problems, keep the device away from moisture and avoid dust, heat, and direct sunlight. Do not use the device outdoors.
- The device is designed for 19" racks and should only be operated installed in a 19" cabinet.



Danger! Make sure

that you wait before using the device after any transport until the device has reached the ambient air temperature. Great fluctuations in temperature or humidity may lead to moisture within the device caused by condensation, which can cause a short.



1.6 Please observe the electromagnetic compatibility!

• This device complies with the requirements of the EMC and the Low-voltage Directive.



Network security

- The default password shall be changed after the commissioning of the device.
- A reset of the password to default through hardware is not possible. Using MOBA-NMS the password can be modified. In case an access via MOBA-NMS is not possible, support effort will be needed or the device has to be sent back to the factory.
- All unused services shall be deactivated: FTP, Telnet,...

2 Maintenance

2.1 Troubleshooting: Repairs

Please read carefully Appendix D Troubleshooting if your device does not work properly.

If you cannot rectify the problems, contact your supplier from whom you have purchased the device.

Any repairs must be carried out at the manufacturer's plant.

Disconnect the power supply immediately and contact your supplier if ...

- liquid has entered your device.
- the device does not properly work and you cannot rectify this problem yourself.

2.2 Cleaning

- Please make sure that the device remains clean especially in the area of the connections, the control elements, and the display elements.
- Clean your device with a damp cloth only.
- Do not use solvents, caustic, or gaseous cleaning substances.

2.3 Disposing



Device

At the end of its lifecycle, do not dispose of your device in the regular household rubbish. Return your device to your supplier who will dispose of it correctly.



Packaging

Your device is packaged to protect it from damages during transport. Packaging is made of materials that can be disposed of in an environmentally friendly manner and properly recycled.

3 General Information: Introduction

3.1 Scope of Delivery

Please check your delivery for completeness and notify your supplier within 14 days upon receipt of the shipment if it is incomplete.

The package you received contains:

- DTS 4148.grandmaster
- Mounting set for rack mounting consisting of:
 - 4 pcs nuts for 19" housing
 - 4 screws M6 for the nuts
 - 4 plastic discs for screws M6
- Connector set
 - 1 * spring terminal 6-pole orange
 - 3 * spring terminal 4-pole orange
 - 2 * spring terminal 2-pole orange
 - 1 * spring terminal 5-pole orange
- 2 pcs mounting tools with spring terminals

3.2 Technical Data

See Appendix "H Technical data".

3.3 Device Description in this Manual

This instruction manual is for the time server **DTS 4148.grandmaster**.

3.4 Introduction

The DTS 4148.grandmaster is an NTP Time Server for use in network environments. It can be synchronized by DCF or GPS (e.g. from GPS 4500), AFNOR-A/C, IRIG-B¹ and NTP, and act as an NTP server in a network.

This device is a PTP grandmaster according to IEEE 1588-2008 for the synchronization of PTP clients.

It can be used as a master clock for NTP slave clocks, synchronized via unicast or multicast with NTP and time zone table.

It is equipped with 2 LAN interfaces for the operation in two independent networks.

In addition, the DTS 4148 provides an IRIG/AFNOR line (available as analog and digital (current loop and RS422) output), a serial interface for the output of time telegrams as well as an output line for technical pulses (pulse/frequency/DCF).

As the "main" master clock, the DTS 4148 can synchronize other master clocks or other equipment with DCF and monitor with 1 alarm input.

The DTS 4148 can send both e-mails and SNMP traps for alerting purposes.

Using MOBA-NMS and SNMP, the DTS 4148 can be fully operated and its configuration and system status can be requested.

To maintain a redundant time source, two DTS 4148 can be linked by an optical link.


¹ With IRIG-B synchronization the date must be set manually once or by another time source (GPS).

3.5 Device types

Model: Features:		Product no.:
DTS 4148.grandmaster	According to above description with OCXO (temperature compensated quartz)	117983

3.6 DTS Distributed Time System

DTS (Distributed Time System) is a system developed by Moser-Baer AG to connect decentralized master clocks, slave clock lines and time servers. For communication, standard LAN (Ethernet) is used. The DTS can be centrally operated and monitored.



3.7 MOBA-NMS - Network Management System

MOBA-NMS is software used for central management and inquiry of state and alarm information. It supports DTS devices as well as all MOBATime analog and digital network clocks and can handle a network with more than 1000 devices. This software provides extensive functions for the configuration, installation, back-up / recovery etc. especially for DTS devices.

Due to the DTS concept, MOBA-NMS can be installed multiple times in one network. With different user rights on the device and software level, the configuration abilities of different users can be set as required.

For DTS devices, all communication is conducted over SNMP V3. The SFTP protocol is used for broadcasting files.

3.7.1 Overview of the main functions

The main MOBA-NMS functions for DTS devices and network clocks are listed below:

- automatic device scan over multicast or IP range
- device management using user-defined device groups → see chapter "3.7.2 Device management"
- intuitive user interface with input check for the device configuration
- status / alarm request and display on the device group level
- device firmware update for one or several devices (parallel)
- support for device commands, e. g. reset, restart etc.
- back-up / recovery of DTS devices
- transfer of the whole DTS configuration to another device
- user management with different access rights
- monitor for NTP and time zone packages
- editor for time zone files
- online help
- etc.


3.7.2 Device management

All MOBATime network devices are displayed in the so-called device view. Here, the devices can be grouped according to user-defined criteria. For this, the individual devices can simply be moved to the according groups and sorted using drag and drop. There is no limit to the number of groups and sub-groups.

Besides the organizational advantages (easier locating, better overview), a device group has the following advantages:

- commands and device updates can be applied to the whole group (including sub-groups).
- Alarms and errors of included devices are displayed on the group level.
- Complete groups can be moved / sorted among themselves.


The content of the device view can be saved and opened at a later time. The created structure and breakdown into groups is preserved.



4.1 LED displays front side

	6		
power	alarm	sync	LAN 1 LAN 2 USB
Description	Color	Status	Description
Power	Green	On Off	Mains or DC power supply is in order No power supply
Alarm	Red	On Off	The alarm relay signalizes an alarm No active alarms
Sync	Green	On	DTS 4148 can read the time from a synchronization source
Off Synchronization source is not available LAN 1 control lamps:			
Left	Green Orange	Blinking Blinking	Network activity No connection to network
Right	Yellow	Off On	10 Mbit 100 Mbit
LAN 2 control lamps:			
Left	Green Orange	Blinking Blinking	Network activity No connection to network
Right	Yellow	Off On	10 Mbit 100 Mbit





4.3 Display

Display showing the current status of the DTS 4148.

Time	16:41:04
Date	22.04.10

Display of:

-Time, date -Current time source -Stratum of the DTS 4148, status: Master / Slave -Software version -IPv4 address LAN 1 -IPv4 address LAN 2 -IPv6 address LAN 1 -IPv6 address LAN 2 -Alarm summary -Current alarms

The display can be operated by means of the corresponding "Display" button:

First press the button briefly:	Switch on the background light
Other buttons to press briefly:	Scroll through all displays
Press button longer (>3 sec):	Change to default display (time and date)

The display changes after approx. 3 min without pressing the button for the default display and the background light goes off.

If a USB stick has been plugged in, it will be displayed. If only telegram files should be copied or the network settings should be changed, this can be activated directly with the button. (Press the button until the copy process starts).

5 Installation

5.1 Connections

The connections are specified in Appendix "A Connection diagrams".

Only connect the designated devices to the various inputs and outputs.

5.2 Boot procedure of the DTS 4148.grandmaster

The normal booting time of the DTS 4148 is approx. 60 sec. with pre-set IP or with DHCP. The booting procedure of the operating system is displayed on the serial console. After that, the text "starting" appears on the display (during the booting procedure the display is dark and empty). Without connection to a DHCP server, the first start up can take up to 75 seconds. After that, the DHCP option must be set to "off" in the network configuration.

The display "starting" remains until the time of output to the lines. The duration, depending on the configuration, is 5-30 sec.

5.3 Initial configuration

Per default, the LAN 1 interface is configured with DHCP on. After booting in a network with DHCP server, the received IP address can be displayed.

The LAN 2 interface is configured with the following static settings per default: IP 192.168.1.5, Subnet 255.255.255.0, Gateway 192.168.1.1

If these possibilities do not work out for the initial configuration, the network configuration can be modified using a USB stick. For this purpose, a text file named **DTS4148NW.conf** is created and filled with the corresponding parameters (not all parameters are required):

IP1:192.168.1.3 SUB1:255.255.255.0 GW1:192.168.1.1 IP2:10.0.0.7 SUB2:255.255.240.0 GW2:10.0.0.1

The insertion of the USB stick is displayed. For taking over the network settings, press the button until the normal time display reappears.

5.4 Firmware

It is recommended to install the current firmware on your device prior to the definite commissioning. The current firmware can be found under *www.mobatime.com* \rightarrow *Customer Data* \rightarrow *Product Ressources* \rightarrow *Time Server.*


5.5 Basic settings (factory settings)

The basic settings can be found in the table in Appendix "G Parameters".

6 Operation

6.1 General

Operation occurs via a terminal menu or SNMP. SNMP operation is explained in chapter "9 SNMP". Operation with the terminal menu takes place either via Telnet or SSH. After a connection has been set up, the login screen is displayed:



To start the menu, *dts* must be logged in as user. The standard password is *dts*. (Changing the password \rightarrow see chapter "6.5.20 General settings").

Only one menu can be open at any time. The first menu started has priority. The menu is automatically closed after 15 min. without operation, and any possible connection via Telnet or SSH is interrupted.

Backspace:

Backspace must be set to "delete" with the serial terminal:

Local echo:

Some terminals (serial or Telnet) do not display the characters entered. It is, therefore, necessary to switch on the "local echo" in the terminal.


6.1.1 Telnet

Windows XP, 7, 8, 10:	Start → Run → <i>telnet [IP address]</i> or with Putty User: <i>dts</i> Password: standard password <i>dts</i> NetTerm (Shareware)
Linux:	Start console and enter "telnet [IP-address]

6.1.2 SSH

Windows XP, 7, 8, 10:e.g. with PuttyLinux:Start console and enter "ssh dts@[IP address]"

6.1.3 Menu structure



The current menu is always displayed in the **menu title**. The **menu options** show all the selectable menu functions. Provided the menu item is not a further menu, the set **parameters** are displayed. Error messages (e.g. invalid entries) or additional information to the selected menu items are displayed in the **response line**. The **input line** shows the current input values or options possible. The **status line** only appears, when an information has to be displayed, e.g. "An alarm is active".

All entries must be completed with ENTER (Return) (e.g. also ESC). The menu window can always be exited with *Ctrl-C* (incl. termination of the Telnet and SSH connection).

The desired menu can be selected with the relevant number.

The numbers 98 and 99 are always used identically:

- With 98, the settings entered are saved and the menu exited. Depending on the change, the DTS 4148, or only partial functions, are rebooted.
- With 99, all changes to the menu are reversed and the menu exited. In the menus where data cannot be saved (command 98), the menu is only exited with 99, but any changes are not saved.

The current menu is updated, without any further entry, with ENTER.


6.2 MOBA-NMS operation

For the configuration of DTS devices via GUI, MOBA-NMS (see chapter "3.7 MOBA-NMS - Network Management System") can be used. All configuration possibilities are subordinated in different configuration pages (called "tabs"). These tabs are connected to the terminal menu and designated accordingly. Example: The terminal menu "Configuration \rightarrow Alarms" can be found in MOBA-NMS under the tab "Alarms".

🚥 DTS 4148 (Client Device) 🐹 DTS 4148 Status: OK Firmware version: 01170214.010000.010000 Version details.. List of active alarms Network Power Interface 1 Interface 2 Power supply Quartz correction IPv4 IPv6 Voltage supply 1 [V]: 24.1 Current supply 1 [mA]: 147 DHCP: Off IP address: 172, 16, 31, 150 Voltage supply 2 [V]: 1.7 Subnet mask: 255.255.240.0 Current supply 2 [mA]: 0 Gateway: 172.16.18.1 DNS server: no info Host name: DTS4148 Alarm history... Time, time state Source Local NTP Internal time (UTC): Feb 23, 2017 6:57:15 AM Stratum and status: 1 MASTER Actual measured offset: 0s 1775us Last measured drift: 0.2219ppm Last time received DCF: Feb 23, 2017 6:56:00 AM Last quartz correction (UTC): Feb 22, 2017 8:15:01 AM Sec. counter DCF: 30 Time source: DCF Last time received link: Jan 1, 1970 12:00:00 AM Offset to source [us]: 0 Sec. counter link: 0 Last time info from source: Feb 23, 2017 6:56:01 AM litter of the source [us]: 0 NTP state Quality of the source: 100% Show NTP status details... Refresh Next refresh: 2 min. 15 sec. Overview Outputs Time handling Alarms PTP settings Network SNMP General, Services configuration pages (tabs)

Configuration example:

For further details on the general MOBA-NMS operation, check the integrated online help (menu "Help \rightarrow Show help").



6.3 Main menu

```
    10.241.0.5 - PuTTY
    DTS 4148.grandmaster Moser-Baer AG
    maintenance
        (Configuration of the lines, timesource state, version
        Configuration of the lines, timesources, alarms ...)
    3 Maintenance
        (Update, backup ...)
    99 Exit DTS menu
    Enter desired menu number>
```


Menus:

Status:	Display of various information regarding operation and environment See chapter "6.4 Status menu"
Configuration:	Configuration of the DTS 4148 See chapter "6.5 Configuration menu "
Maintenance:	Software update, backup and restore See chapter "6.6 Maintenance menu"

6.4 Status menu

The status menu consists of 2 pages.

Status menu page 1:



The menu shows various information on the current operating status.

- Requesting alarm status, display of all the DTS 4148 active errors. Display of the DTS 4148 alarms (64) on 4 pages. The ALARM DETAIL menu pages can be scrolled through with ENTER. Active alarms are displayed with a *. The ALARM DETAIL menu page can be exited with 99. All DTS 4148 active alarms are displayed, masking (e-mail, traps, relay) only occurs later.
- Alarm history display. Display of the DTS 4148 alarm record, newest alarm first. The ALARM RECORD menu pages can be scrolled through with ENTER. The ALARM RECORD menu page can be exited with ESC. Max. length of error report: 240 messages.
- 3. Current time and status display. See chapter "6.4.1 Time information and status"
- 4. Time source information display. See chapter "6.4.2 Time source information"
- 5. Power supply information (current, voltage) display.
- 6. Current network configuration display. With ENTER, a second page can be displayed with network information.
- 7. DTS 4148 system information display (internal status, regulation voltage of the quartz..). This information is for support purposes only.
- 8. Product information like serial number, firmware version etc.
- 9. All respective software versions of the DTS 4148 components.

Status menu page 2:

```
Press enter for next part, 99 to leave>
```

Display of information with regard to the internal state of the NTP server.

6.4.1 Time information and status

```
🛃 10.241.0.5 - PuTTY
                                                                            - U ×
                                                                                 ٠
   DTS 4148.grandmaster
                        Moser-Baer AG
   TIME INFORMATION AND STATUS
   Internal time of the DTS (local time)
                                                16:10:03 26.08.14
   Stratum and state of DTS
                                               1 MASTER
   Last measured drift
                                                -0.0007ppm
   Last quartz correction
                                                12:44:48 26.08.14 UTC
                                                GPS (DCF)
   Time source
   Offset to source
                                               0.0us
   Last time information from source
                                               14:10:00 26.08.14 UTC
   Jitter of the source
                                                0.1us
   Quality of the source
                                                100%
   99 Return
   Enter desired menu number>
- Internal time of the DTS:
                                      local time
- Stratum and status of the DTS:
                                      current stratum,
                                      status: MASTER, SLAVE, not defined
- Last measured drift:
                                      drift before the last quartz correction
- Last quartz correction:
                                      time of the last quartz correction
```

current time source

quality of the source

current jitter

offset to source (source - system time)


time of the last information from source

- Time source:
- Offset to source:
- Last time info. from source:
- Jitter of the source:
- Quality of the source:

6.4.2 Time source information

```
🚰 10.241.0.5 - PuTTY
                                                                           - 🗆 🗵
   DTS 4148.grandmaster Moser-Baer AG
   TIMESOURCE INFORMATION
   Actual measured offset
                                               Ous GPS FULL
   Last time received DCF (UTC)
                                               14:10:00 26.08.14 (8)
   Sec. counter DCF
                                               40
   Last time received link (UTC)
                                               00:00:00 01.01.70
   Sec. counter link
                                               0
   NTP source
                                               Antenna (DCF/GPS)
   NTP source offset
                                               0us
   NTP source jitter
                                                1us
   NTP source stratum
                                                0
   99 Return
   Enter desired menu number>
- Currently measured offset:
                                      last measured offset with source info and type of
                                      measurement (only needed for Moser-Baer
                                      support).
- Last time received DCF:
                                      last time received from DCF source
                                      In (): Information about number of available
                                      satellites (only for GPS 4500 and GNSS 3000).
                                      For DCF, this value is random.
- Sec. counter DCF:
                                      the counter is incremented by 1 with each DCF
                                      pulse. For the minute marker, the counter is set
                                      to 0.
- Last time received link:
                                      last time received from DTS Link
- Sec. counter link:
                                      analogue sec. counter DCF
- NTP - Source:
                                      current time source (system-peer) of the NTP
                                      Server
                                      Antenna = DCF or GPS
- NTP source offset:
                                      current offset of the NTP Server
- NTP source jitter:
                                      jitter of the current source
- NTP source stratum:
                                      stratum of the current source
```

6.5 Configuration menu



Configuring the DTS 4148 through various submenus:

- 1. Configuring the lines / outputs (DCF/pulse/frequency, serial interfaces, IRIG/AFNOR/DCF-FSK and NTP slave clock line) See chapter "6.5.1 Lines"
- 2. Configuring the time source, time-keeping etc. See chapter "6.5.7 Time "
- 3. Alarm settings (alarm relay, e-mail, SNMP) See chapter "6.5.14 Alarm"
- General settings of the DTS 4148 (language, time zone for alarms and display, password for menu, power supply monitoring...) See chapter "6.5.20 General settings"
- 5. Network Settings See chapter "6.5.21 Network"
- 6. Services (switching network services such as FTP, Telnet, SSH on or off) See chapter "6.5.22 Services (network services FTP, telnet, SSH...)"
- SNMP Configuration for GET/PUT.
 See chapter "6.5.23 SNMP" (Traps are dealt with in menu '2. Configuration' →'3.
 Alarms' → '3. Traps'. See also chapter "6.5.18 SNMP traps")

6.5.1 Lines

Under lines, settings can be undertaken for the following functions:

1 DCF - Output

- → see chapter 6.5.2
- 2 DCF / Pulse / Frequency output
- 3 Serial Interface
- 4 IRIG / AFNOR / DCF-FSK output
- 5 NTP slave clocks / time zone server
- → see chapter 6.5.3
- → see chapter 6.5.4

- → see chapter 6.5.5 → see chapter 6.5.6

6.5.2 DCF – output

The DTS 4148 is equipped with one DCF output line. This line is available on the electrical current loop DCF output.

🛃 10.241.0.5 - PuTTY		
DTS 4148.grandmaster Moser-Baer AG		A
DCF OUTPUT 1 Mode (0=off, 1=DCF) 2 Time zone	1 [0] UTC	
98 Return and save 99 Return and discard changes		
Enter desired menu number>		
		•

- 1. Select line function: off or DCF on
- 2. Select time zone → see chapter 6.5.26 Time zone selection.

6.5.3 DCF / Pulse / Frequency output

```
🚰 10.241.0.5 - PuTTY
                                                                           - 🗆 🗵
  DTS 4148.grandmaster
                        Moser-Baer AG
  DCF / PULSE / FREQUENCY OUTPUT 1
  1 Mode (0=off, 1=DCF, 2=pulse, 3=frequency) 1
  2 Time zone
                                                [0] UTC
  3 Pulse type (0=sec 1=min 2=hour 3=user)
                                               1
                                               150ms
  4 Pulse length
  5 User defined pulse type
                                               1sec
  6 Correction of output
                                               Oms
  7 Frequency
                                               5000000Hz
  98 Return and save
   99 Return and discard changes
  Enter desired menu number>
```


- 1. Select line function: Line switched off, line DCF output, line pulse output, line frequency output
- 2. Select time zone \rightarrow see chapter 6.5.26 Time zone selection.
- 3. Select pulse mode: every second, minute, hour or user-defined. (Only active with the pulse output function)
- 4. Select pulse length in ms (1-500ms) (Only active with the pulse output function)
- 5. User-defined pulse interval (1-3600 sec) only active with pulse type 3 (=user) (the value is also only then displayed). The pulse always occurs after a multiple of the pulse interval from the 0 second in the 0 minute, e.g.:
 - Pulse interval 960 sec. (16 min.)
 - → Pulse occurs: 00:00:00, 00:16:00, 00:32:00, 00:48:00, 01:00:00, 01:16:00 ...
 - Pulse interval 25sec
 - → Pulse occurs: 00:00:00, 00:00:25, 00:00:50, 00:01:15, 00:01:40, 00:02:05 00:59:35, 01:00:00, 01:00:25 ...
- 6. Output correction (-500ms...+500ms)
- 7. Frequency 1Hz ... 5MHz

Important: Only frequencies which fulfill the following requirements are to be used, otherwise, phase shifts occur: 20'000'000 / frequency = whole number value


Important: Frequencies above 2 MHz are not sent out as a square-wave signal anymore.

6.5.4 Serial interface

Serial telegram output via RS232, RS422 or RS485.



- 1. Select mode: Line switched off / on
- 2. Select time zone \rightarrow see chapter 6.5.26 Time zone selection.
- 3. Com mode:
 - 1 = send RS 232 (receive is not enabled)
 - 2 = send and receive RS232
 - 3 = send and receive RS485
 - 4 = send RS 422 (receive is not enabled)
- 4. Baudrate: 300, 600, 1200, 2400, 4800, 9600, 19200, 38400
- 5. Data bit: 7 or 8
- 6. Stop bit: 1 or 2
- 7. Parity: none, even, odd
- 8. Selecting telegram file changes to the menu "SELECTION OF FILE"



Notice: No flow control available.

The description of the telegram function and the telegram file can be found in Appendix E Serial Telegrams.

Selection of the telegram file:

```
Page 1
Pa
```


The copy procedure of telegram files is explained in chapter "7.10 Copying Telegram files to the DTS 4148.grandmaster".

6.5.5 IRIG / AFNOR / DCF-FSK Output

```
🚰 10.241.0.5 - PuTTY
                                                                     - 🗆 🗵
                                                                         *
  DTS 4148.grandmaster Moser-Baer AG
            _____
  IRIG / AFNOR OUTPUT 1
                                           IRIG-B126
  1 Mode
  2 Time zone
                                           [0] UTC
  3 Level (~Upp @ Ri=Rl=500hm)
                                           2000mV
  4 Alarm signal level low (~Ueff)
                                           200mV
  98 Return and save
  99 Return and discard changes
  Enter desired menu number>
```

- 1. Select mode: see picture below
- 2. Select time zone \rightarrow see chapter 6.5.26 Time zone selection.
- Configuration of the output voltage level (100 5500 mV): The defined voltage corresponds to the expected output amplitude when power matching (impedance matching) with a load of 50 Ohms is fulfilled. The output voltage is not controlled, resp. it is not adjusted in case of a load change.
- Configuration of the output voltage level supervision (0 2000 mV): When the output voltage falls below the defined voltage level, an alarm is released.

Selection line function:




Notice:

With the activation of one of this outputs, the modulated and the digital output are activated at the same time. Example: To activate IBIG-B002 output, the Code 01: IBIG-B (B122) has to be se


To activate IRIG-B002 output, the Code 01: IRIG-B (B122) has to be set for the corresponding output.

6.5.6 NTP slave clocks / time zone server


NTP slave clock line for operating slave clocks on the LAN (Ethernet). With this clock line, a world time function can be realized.



- 1. Mode of clock line: 0 = off, 1 = Send NTP multicast, 2 = Send NTP multicast and time zone table, 3 = Send time zone table, 4 = Time zones on request, 5 (only for maintenance) = Send an empty time zone table and return to previous mode.
- 2. Multicast adress for NTP and time zone server: **239.192.54.x** Group address: x = 1-15 for MOBATIME devices, e.g. NCI, SEN 40.
- 3. Multicast port for Time zone server (enter an arbitrary value, empty is not allowed! Value e.g.: 65534). The port is also needed for requesting time zone entries (mode 4).
- 4. Poll-interval for NTP Multicast in 2^poll-values in seconds (range: 1 16).
 E.g. poll-value = 2 → interval: 2² = 4 sec., poll-value = 5 → interval: 2⁵ = 32 sec.
 For redundant Multicast time servers see remark next page.
- Packet time to Live (TTL) for NTP- and time-zone-Multicast-packets in hops. (Number of Routers in a network to transfer the packets through; for simple network without routing, enter value "1", for 1 Router enter "2").
- 6. Repeat time to send time zone table: 10 86400 sec.
- 7. Delay time between the sending of the individual time zone entries (one entry per Multicast packet) of the table: 1 60 sec.
- 8. Configuration of individual time zone entries. Displays menu "TIME ZONE TABLE".



Notice: For the operation of a **multicast** communication (NTP and Time Zone Server) **the configuration of a gateway is required** (see chapter "6.5.21 Network"). The gateway can be set manually or by using DHCP. If there's no gateway available, it's possiible to set the own IP as gateway.



Notice:

Redundant NTP multicast server:

If two NTP servers in the same network should send NTP with the same Multicast IP address (redundancy), then the first time server has to be configured with a small **pollinterval** (e.g. $2 \rightarrow 4$ sec.) and second time server with a large pollinterval (min. 100 x larger, e.g. $9 \rightarrow 512$ seconds). As long as the first time server is sending NTP Multicast packets, the packets from second time server are ignored. This configuration is needed, to reach a defined situation for the end devices (the DTS with the more frequently NTP send rate gets higher priority for time reception).

Time zone table for the NTP slave clock line:

Display of all time zone entries (15) of time zone servers for NTP slave clock lines.

Choose a zone number to change selected zone.

Time zone selection \rightarrow see chapter "6.5.26 Time zone selection".

The page can be exited with 99. Changes are first stored or reset on the overlying menu page.

6.5.7 Time handling

Under time administration, settings can be undertaken for the following functions:

- Time source configuration → see chapter "6.5.8 Time source "
- Time adjustment configuration → see chapter "6.5.9 Time adjustment / Time-keeping"
- Redundant operation → see chapter "6.5.10 Redundant operation"
- NTP Server → see chapter "6.5.11 NTP server"
- For setting the time manually → see chapter "6.5.12 Manual time set / Leap second"
- PTP server → see chapter "6.5.13 PTP Server"

6.5.8 Time source

Time source configuration.

🚰 10.241.0.5 - PuTTY		
DTS 4148.grandmaster Moser-Baer AG		
TIME SOURCE		
1 Source type	2	
2 Time zone of the source	[0] UTC	
3 Alarm delay for failure of the source	9min	
4 DTS stratum (0=auto, 1-15=fix)	0	
5 Stratum limit for synchalarm	12	
6 Stratum TO (1-16) DCF/GPS fail	1h	
7 Offset per stratum	50ms	
8 Max. offset for time ok	50000us	
9 Time source correction (DCF/GPS only)	-1700ns	
98 Return and save		
99 Return and discard changes		
-		
Enter desired menu number>		
		_
		<u> </u>

- 1. Type of time source: 0=none, 1=DCF low quality, 2=GPS-DCF high quality, 3=NTP, 4=AFNOR-A/C or IRIG-B 12X
- 2. Time zone of the source: see chapter 6.5.26 Time zone selection.
- 3. Alarm delay at failure of time source (minutes):

	,	0 = off, 1-2'160min, default = 0 Error: "loss of time source TO" resp. "loss of local source" in redundant mode as slave
4.	DTS stratum:	0=Stratum is automatically calculated according to

- the time source (see chapter 8.3). 1-15=Stratum is set on a fix value
- 5. Stratum limits for alarm: Limits for alarm "Time source stratum lost" (1-16)
- Stratum TO (Timeout): Duration of stratum change 1 to 16 in the case of time loss (1-999h), e.g. 24 hrs → stratum counts up from 1 to 16 within 24 hrs. Default value: 12h
- Offset per Stratum in ms (0 40'000 ms). Stratum is calculated with this value when time is received again:
 Offset/Stratum = 30 ms, offset of the time source 150 ms → Stratum = 5
- 8. Max. offset for time source to set valid time in μ s at start up. (0-1'000'000 μ s)
- 9. Time source correction (only for DCF), +/-60'000ms

For description of time source see chapter "8 Time administration"

6.5.9 Time adjustment / Time-keeping

```
🛃 10.241.0.5 - PuTTY
                                                                          - 🗆 ×
   DTS 4148.grandmaster
                         Moser-Baer AG
   TIME ADJUSTMENT CONFIGURATION
   1 Adjust mode (0=follow, 1=set)
                                               1
   2 Max. catch up speed
                                               100000ns/s
   3 Time core type (0-255, default 0)
                                               1
   4 Synch. only offset
                                               Oms
   5 RTC mode
                                               0
   98 Return and save
   99 Return and discard changes
   Enter desired menu number>
1. Adjust mode:
                             0=time is slowly adjusted
                             1=time is set immediately
2. Maximum catch up speed in ns/s (0-10'000'000).
3. Quartz type:
                             Standard=0 (0-255)
                             0=off
4. Synch. only offset:
                             100-5000ms=Limits as from which time is no longer
                             accepted → Alarm "Syn only diff too great"
5. RTC mode
                             0=RTC deactivated
                             1=ON, with initial time set, independent of the mode (1)
                             2=ON
Notice:
             Explanation to the RTC mode:
             RTC mode 0:
             After startup of the device the system time starts at 00:00. First of all, the
             device has to receive the time from its time source. The time adjust
             happens according to the
             "1 Adjust mode".
             RTC mode 1:
             The internal real time clock (RTC) is activated. After startup of the device
             the system time is set with the RTC time.
```

The first takeover of the time from the time source happens in one step, independent from the Adjust mode (1) setting.

RTC mode 2:

The internal real time clock (RTC) is activated. After startup of the device the system time is set with the RTC time.

The time takeover from the time source happens according to the Adjust mode (1).

→ Adjust mode = 0: time is slowly adjusted

Adjust mode = 1: time is set immediately



Important! For the redundant operation, the RTC mode should be switched off!

For a description of time-keeping see chapter "8 Time administration"

6.5.10 Redundant operation

```
🚰 10.241.0.5 - PuTTY
                                                                         - 🗆 🗵
   DTS 4148.grandmaster Moser-Baer AG
  REDUNDANT OPERATION
  1 Mode (0=single, 1=red., 2=red. LAN1-LAN2) 0
  2 Stratum limit (1-16)
                                              3
   3 Max. offset to slave source
                                             100000us
   4 Port for LAN link
                                              14338
                                             10.241.0.53
   5 IP address 2. DTS 4148
   6 Set master manual
   98 Return and save
   99 Return and discard changes
  Enter desired menu number>
```

1. Mode: 0=single operation

1=redundant operation of 2 DTS 4132 (Master-Slave operation) 2=redundant operation of 2 DTS 4132 (Master-Slave operation) without LAN communication between the 2 devices.

- 2. Stratum limit to switch from slave to master. Standard 16 (1-16)
- 3. Max. offset of slaves to the slave time source for triggering the alarm "Offset Source (Slave)" (0-5'000'000us)
- 4. Port for LAN-Link. default 14338
- IP address of the 2nd DTS 4148. Only required if the optical link is not working. Format 10.241.23.99
 ENTER without entering an address will delete the entry.
- 6. Manual change from slave to master. The command is effected immediately. Saving with '98' is not required when exiting the menu.

For a description of redundant operation, see chapter "8.12 Redundant operation of 2 DTS 4148.grandmasters"

- **Important!** In redundant operation, no additional NTP servers may be configured as backup sources.
- Important! For the redundant operation, the RTC mode should be switched off!

Important! LAN link in redundant mode: For the redundant operation with additional LAN link, only the LAN 1 can be used. If this is not possible, select redundant Mode 2. The LAN link is only used for internal communication between the two servers. It is not a redundancy for the optical link.



6.5.11 NTP server

NTP can run as server or combined as server/client. To run NTP as source (NTP as client), in the menu '2. Configuration' \Rightarrow '2. Time handling' \Rightarrow '1. Time source setting' \Rightarrow '1. Source type' choose NTP and set at least one server. If NTP server is configured, but NTP is not indicated as time source, NTP only runs as backup time source (redundancy) to the actual time source.

The exact behavior of NTP time sources is described in chapter "8.5 Time acceptance from NTP".

Further two multicast or broadcast addresses can be configured.

```
🛃 10.241.0.5 - PuTTY
                                                                        - 🗆 🗵
                                                                            ٠
  DTS 4148.grandmaster Moser-Baer AG
   _____
            ------
  NTP SERVER CONFIGURATION
  1 Configuration timeserver address 1
                                             10.241.0.16
  2 Configuration timeserver address 2
  3 Configuration timeserver address 3
  4 Configuration timeserver address 4
  5 Configuration multi-/broadcast address 1
  6 Configuration multi-/broadcast address 2
  7 NTP Authentication / Access
     NTP slave clock line (info only)
  99 Return
  Enter desired menu number>
```

1.-4. Summary about configured NTP – time sources. Select to configure.

5.-6. Summary about configured NTP – broadcast addresses. Select to configure.

7. NTP Authentication: Changes to the menu "NTP AUTHENTICATION" Information about a multicast – address, configured for NTP slave clocks.

Configuration of the individual server/peer address is as follows:

₽ 10.241.0.5 - PuTTY		
DTS 4148.grandmaster Moser-Baer AG		
ENTRY TIMESOURCE	1	
2 Minpoll	3	
3 Maxpoll	5	
4 Server/Peer	server	
5 Prefer	prefer	
6 Authentication key	off	
98 Return and save		
99 Return and discard changes		
55 Keturn and distard changes		
Enter desired menu number>		
		▼

- 1. Insert time sources (IP address or name, e.g. "ntp.metas.ch") ENTER without entry of an address will delete value.
- 2.-3. Configurations of Minpoll and Maxpoll: Inquiry interval 2^poll value in seconds.
 0 = automatically
 e.g. poll value=2 → intervall 2: 2² = 4sec., poll value=5 → intervall 5: 2⁵ = 32sec.
 Range of poll values (exponent): 1 16
 To get an exact synchronization it's better to limit Maxpoll to 6 (64 sec.).
- 4. Set type of NTP inquiry: server or peer
- 5. Preferred source: on or off
- 6. Authentication key: off, key number, autokey
- **Notice:** If a key number is entered, the entered key must also be added to the trusted keys.

i	Notice:
i	Notice:
i	Notice:

Notice:	All changes lead to a restart of the NTP server!
Notice:	If NTP only runs as a backup (source DCF or GPS), no NTP source should be indicated as prefer !
Notice:	Maxpoll should not be selected under 4 (16 sec), as otherwise, internal trimmung may be inaccurate. Maxpoll and Minpoll on automatic can lead to insufficient synchronization accuracy. The specified accuracies were measured with Minpoll = 3 and Maxpoll = 6. The configuration server should be used whenever possible.

Configuration of the Multi- / Broadcast address is as follows:


```
🚰 10.241.0.5 - PuTTY
                                                                           - 🗆 🗵
                                                                                ▲
   DTS 4148.grandmaster Moser-Baer AG
  NTP MULTI- / BROADCAST-ENTRY
                                               1
  1 Multi- or broadcast IP address
                                               4sec
  2 Interval
  3 TTL (only for multicast)
                                               1hops
   4 Authentication key
                                               off
   98 Return and save
   99 Return and discard changes
  Enter desired menu number>
```

- 1. IP address of the destination network (multicast or broadcast). ENTER without entering an address will delete the entry.
- Interval for sending out the NTP information in seconds. The interval is rounded after the entry to NTP standard, which only permits values of format 2^x: 1,2,4,8,16,32,64... Maximum 65536 seconds.
- 3. TTL (time to live) in hops. Only required for multicast. Number of routers over which the multicast packet should be transmitted: for simple networks without a router - enter 1, for 1 router - enter value 2.
- 4. Authentication key: off, key number, autokey

Notice: All changes lead to a restart of the NTP server.

Configuration of the NTP authentication:

The NTP authentication is described in chapter "8.10 NTP Authentication".



1. Import keys (from /ram directory) The file ntp.keys must first be copied into the directory /ram.

Notice: The file must be named exactly in this way and written entirely in small letters.

- 2. Export keys (to /ram directory) The current ntp.keys file is written in the directory /ram.
- 3. Select the trusted keys separated by space
- 4. Select the request key
- 5. Select the control key
- 6. Set the auto key password

7. Execute for auto key commands:

•	Execute for auto key commands.		
	gen_iff	generate the IFF certificate	
	gen_gq	generate the GQ certificate	
	gen_mv*	generate the MV certificate	
	gen_all*	generate all (IFF,GQ,MV) certificates	
	gen_client	generate the client certificate	
	update_server	update the server certificate	
	update_client	update the client certificate	
	export_iff	export the IFF server certificate to /ram. Parameter password	
		of the client	
	export_gq	export the GQ server certificate to /ram.	
	export_mv*	export the MV server certificate to /ram.	
	import_iff	import the IFF server certificate from /ram.	
	import_gq	import the GQ server certificate from /ram.	
	import_mv*	import the MV server certificate from /ram.	
	clear_ram	delete the certificates in /ram	
	clear_keys	delete the certificates in the NTP key directory	

Example: *export_iff myPassword* exports the IFF client certificate to /ram.

*MV schema is currently not available

6.5.12 Manual time set / Leap second

```
    DTS 4148.grandmaster Moser-Baer AG
    Total TIME SET
    Set time (UTC)
    Adjust time
    Leap second mode 0
    Leap second date (UTC) 00:00:00 01.01.15

    98 Return and save
    99 Return and discard changes
    Enter desired menu number>
```

- 1. Set UTC time in the format "hh:mm:ss DD.MM.YY". Time is set with ENTER!
- 2. Correct time in ms (- = backwards). Range: +/-10'000ms Time is set with ENTER!
- 3. Leap second mode:
 - 0 off
 - 1 Additional second will be inserted at entered time Is set to 0=off after inserting the leap second.
 - -1 Second will be left out at entered time Is set to 0=off after inserting the leap second.
 - 2 Recognize leap second automatically. Only possible with a source with leap second announcement!
- 4. Set UTC time of leap second in format: "hh:mm:ss DD.MM.YY"

For a description of the leap second, see chapter "8.9 Leap second"

6.5.13 PTP Server

The PTP menu consists of 2 pages:

PTP configuration page 1:

₫	10.241.0.5 - PuTTY DTS 4148.grandmaster Mo	ser-Baer AG	
	PTP CONFIGURATION 1 Mode (0=aus, 1=Master) 2 Interface 3 Profile 4 Delay mechanism 5 Transport protocol 6 IPv6 scope 7 UTC leap offset (TAI-U 98 Return and save 99 Return and discard cha Enter desired menu number	nges	Ţ
2. 3.	Mode Interface Profile Delay mechanism	0 = off, 1 = master 0 = LAN1, 1 = LAN2, 2 = both, default LAN1 0 = none, 1 = default, 2 = utility 0 = E2E, 1 = P2P, default E2E	

- 5. Transport protocol 0 = IPv4, 1 = IPv6, 2 = layer 2, default IPv4
- 6. IPv6 scope 1..15, default 15 (0xE)
- 7. UTC switch second offset (TAI-UTC)

Press ENTER to change to page 2.

PTP configuration page 2:

DTS 4148.grandmaster Moser-Baer	AG	
	===	
PTP CONFIGURATION	Page 2	
11 Priority 1	128	
12 Priority 2	128	
13 Domain	0	
14 Announce interval	0	
15 Sync interval	-1	
16 Announce TO	2	
98 Return and save		
99 Return and discard changes		
Enter desired menu number>		
Enter desired menu humbers		

TT. Phoney I	0-255, default 126
12. Priority 2	0-255, default 128
13. Domain	0-4, default 0
14. Announce interval	0-4, default 1, values in format 2 ^x sec (every 2 sec)
15. Sync interval	-11, default 0, values in format 2 ^x sec (every sec)
16. Announce TO	210, default 3, values in format 2^x sec (after 8 sec)
Droop ENITED to obongo to	


Press ENTER to change to page 1.

6.5.14 Alarms

Under alarms, settings can be undertaken for the following functions:

- Alarm relay → see chapter 6.5.15
- E-mail → see chapter 6.5.17
- SNMP traps → see chapter 6.5.18
- Alarm input \rightarrow see chapter 6.5.19

6.5.15 Alarm relay



1. Alarm mask for relay (see chapter "Fehler! Verweisquelle konnte nicht gefunden werden. Alarm mask")

6.5.16 Alarm mask

Γ

🛃 10.241.0.5 - PuTTY		
	-	
DTS 4148.grandmaster Moser-Baer AG		
ALARMMASK Page 1		
[]=error disabled, [*]=error enabled		
[*] Bit00: DTS restart [*] Bit01: Error bit1		
[*] Bit02: Supply voltage too low [*] Bit03: Failure supply 1		
[*] Bit04: Failure supply 2 [*] Bit05: Error voltage 5V		
[*] Bit06: Error voltage 2.5V [*] Bit07: Error voltage 1.25V		
[*] Bit08: Wrong time zone DCF [*] Bit09: Error Time Zone TC		
[*] Bit10: Error bit10 [*] Bit11: Alarm input		
[*] Bit12: IRIG output voltage lo [*] Bit13: Error bit13		
[*] Bit14: Error bit14 [*] Bit15: Error bit15		
Enter alarmnumber to alter mask		
Press ENTER for next part, 99 to leave>		
	-	

Display of all the DTS 4148 alarms (64) on 4 pages. Pages can be scrolled through with ENTER.

An alarm on the current page can be switched on or off by entering an error number. The page can be exited with 99. The modifications will be saved or restored one menu level higher in "ALARM CONFIGURATION". All Alarms with "error bitxx" are not yet used.

A description of individual errors can be found in appendix "C Alarm list".

The alarm masks for the various applications (E-mail, SNMP, SNMP Traps, alarm relay) can differ.

6.5.17 E-mail

```
🛃 10.241.0.5 - PuTTY
                                                                           - 🗆 🗵
                                                                                *
   DTS 4148.grandmaster Moser-Baer AG
  MAIL CONFIGURATION
                                               Page 1
  1 Mailmode
                                               off
                                               ff ff ff ff ff ff ff ff
  2 Alarmmask for mail
  3 Mailserver
   4 Mailport (default 25)
                                               25
   5 Destination mail address1
   6 Destination mail address2
   7 Reply mail address
   8 From mail address
   98 Return and save
   99 Return and discard changes
  Enter desired menu number>
```

- 1. E-mail function on or off.
- Alarm mask for e-mail notifications (see chapter "Fehler! Verweisquelle konnte nicht gefunden werden. Alarm mask")
 Changes are stored or reset on the overlying menu page "MAIL CONFIGURATION".
- 3. IP address of the mail server e.g. 10.249.34.5 ENTER without entering an address will delete the entry.
- 4. Mail server port (often 25)
- 5.-6. Destination e-mail address. ENTER without entering an address will delete the entry.
- 7. Reply address (e.g. support, administrator...) ENTER without entering an address will delete the entry.
- 8. Sender address (important for authentication through the mail server) ENTER without entering an address will delete the entry.

Press ENTER to change to page 2.

Notice: Configuration of a gateway is required for sending e-mails (see chapter "6.5.21 Network"). This can be set via DHCP or manually.



E-mail configuration page 2:

11. Authentication mode:

0=off (sender e-mail address used for authentication) 1=auto (tries CRAM-MD5, LOGIN- PLAIN in this sequence) 2=PLAIN 3=LOGIN 4=CRAM-MD5

- 12. User name (only for authentication mode 1-4)
- 13. Password (only for authentication mode 1-4)


Press ENTER to change to page 1.

Format of an error message via E-mail:

```
Event <Alarm 03 set: Power failure 1>
Time <11:26:45 10.01.07>
Hostname <DTS4148 (10.241.0.30)>
```

6.5.18 SNMP traps


For a description of SNMP functionality, see also chapter "9 SNMP". Traps are also designated as notifications (from SNMP V2)



- 1. Trap mode on or off (applies to alarm and alive traps)
- 2. Alarm mask for SNMP trap messages (see chapter "Fehler! Verweisquelle konnte nicht gefunden werden. Alarm mask") Changes are first stored or reset on the overlying menu page "SNMP TRAP CONFIGURATION".
- 3. Trap community string (group membership for traps). Standard: *trapmobatime*.
- 4. Configuration of the receiving system (trap sink) 1
- 5. Configuration of the receiving system (trap sink) 2
- Time period for alive messages in seconds. 0 = no alive traps are sent Range: 1-7'200sec
- Notice: General settings for SNMP can be found in menu '2. Configuration' → '7. SNMP'. See also chapter "6.5.23 SNMP").
- **Notice:** Configuration of a gateway is required for sending SNMP traps (see chapter 6.5.21 Network). This can be set via DHCP or manually.
- Notice: Each configuration change leads to a restart of the DTS SNMP Agent.




Configuration of the receiving systems



- 1. Address of the evaluation system e.g. 10.240.0.9. ENTER without entering an address will delete the entry.
- 2. Port of the evaluation system (usually 162).
- 3. SNMP Version: 1=SNMP V1, 2=SNMP V2c
- Notice: Each configuration change leads to a restart of the DTS SNMP Agent.

6.5.19 Alarm input

Description of the functionality of the alarm input.



1. Mode off, on or inverted.

6.5.20 General settings

```
🛃 10.241.0.5 - PuTTY
                                                                           - U ×
                                                                                ٠
   DTS 4148.grandmaster
                        Moser-Baer AG
  GENERAL SETTINGS
   1 Language
                                                0
                                               [+1] Brussel
  2 Timezone displayed times
  3 Power (0=single, 1=red.)
                                               0
   4 Password (menu)
                                               dts
   98 Return and save
   99 Return and discard changes
  Enter desired menu number>
```

- 1. Setting the display language
- 2. Setting the time zone for the display, and also all alarm logs, e-mail and SNMP. (See chapter 6.5.26 Time zone selection).
- 3. Power: 0=simple power, 1=redundant power (See chapter "10 Power supply alternatives")
- 4. Enter password for the menu (user *dts*) (max. 15 characters). A password must be configured.

6.5.21 Network

DTS 4148.grandmaster Moser-Baer AG		
NETWORK GENERAL		
1 IPV4 Configuration LAN 1		
2 IPV6 Configuration LAN 1		
3 Network Interface LAN 1	auto	
4 IPV4 Configuration LAN 2		
5 IPV6 Configuration LAN 2		
6 Network Interface LAN 2	auto	
7 Host name (Device name)	DTS4148	
8 Domain name		
98 Return and save		
99 Return and discard changes		
-		
Enter desired menu number>		

- 1. Configuration of IPv4 parameters LAN 1
- 2. Configuration of IPv6 parameters LAN 1
- 3. Set network interface LAN 1: Auto, 100/10Mbit, half, full duplex.
- 4. Configuration of IPv4 parameters LAN 2
- 5. Configuration of IPv6 parameters LAN 2
- 6. Set network interface LAN 2: Auto, 100/10Mbit, half, full duplex.
- 7. Set host name.



Notice: A host name must always be configured.

Host names and their format are described in the Internet standards RFC 952 and RFC 1123: Domains and host names may only contain letters (capitals or small letters) and numerals ("0-9"). In addition, the minus sign ("-") may also be used, as long as it is not at the end. **Everything else is not permitted!**

8. Set domain e.g. test.org

View of the current network state in Menu: '1 Status' → '6 Info network config.'

Notice:	The menu is closed upon modifying the IP or the DHCP mode.
Notice:	DHCP on/off, each change of this setting will result in a restart of the NTP server!
Notice:	For the operation of a Multicast communication (NTP and Time Zone Server) the configuration of a gateway is mandatory . The gateway can be set manually or by using DHCP. If no gateway is available, the own IP address can be used.

Notice:	Only one DNS server should be configured (IPv4 or IPv6).
Notice:	Modifications to the network must be coordinated with the network administrator!
Notice:	The LAN 1 gateway has priority compared to the LAN 2 gateway!
Notice:	If only one LAN interface is used, it always has to be LAN 1!
Notice:	The two LAN interfaces may not be configured in the same network (subnet)!

Network configuration IPv4:

🛃 10.241.0.5 - PuTTY		_ _ _×
DTS 4148.grandmaster Moser-Baer AG		_
NETWORK IPV4	LAN 1	
1 DHCP	on	
2 IP address	DHCP	
3 Subnet mask	DHCP	
4 Gateway	DHCP	
5 DNS server	DHCP	
98 Return and save		
99 Return and discard changes		
-		
Enter desired menu number>		
		_

- 1. DHCP on or off, the following fields are not available in case of DHCP = on. A DHCP **renew** can also be triggered via this point.
- **Notice:** DHCP on, if no DHCP server is available, leads to longer start-up time (<75 sec.) of the DTS.

2.-5. Set IP address, subnet mask, gateway and DNS server. Format = 10.240.98.7




Network configuration IPv6:

```
🛃 10.241.0.5 - PuTTY
                                                                           _ 🗆 🗵
                                                                               ٠
   DTS 4148.grandmaster Moser-Baer AG
  NETWORK IPV6
                                               LAN 1
   1 Mode / Autoconf
                                               on
  2 DHCPv6
                                               on
                                               fd03:4432:4646:3454::2345/64
  3 IP address 1 / Prefix
   4 Gateway 1
                                               fd03:4432:4646:3454::1
   5 DNS server
                                               0::0
   98 Return and save
   99 Return and discard changes
  Enter desired menu number>
```

- 1. Autoconf on or off
- 2. DHCPv6 on or off
- 3. IP address with prefix in IPv6 format e.g. 2001:2345:6789::12:1:34/64
- 4. Gateway in IPv6 format
- 5. IPv6 DNS server

6.5.22 Services (network services FTP, telnet, SSH...)


Network services configuration:



1.-3. Switch the individual services off or on.

6.5.23 SNMP

For a description of SNMP functionality, see also chapter "9 SNMP".



- 1. Mode. 0=off, 1= V1 + V2c + V3, 2=V2c + V3, 3=V3 only The MIB 2 SNMP information is also available with "Mode = off".
- **Notice:** To send out MIB-2 traps, the trap community and the destination address must at least be configured in menu '2. Configuration' \rightarrow '3. Alarms' \rightarrow '3. Traps'. See also chapter "6.5.18 SNMP traps".
- 2. Alarm mask for SNMP status (see chapter "Fehler! Verweisquelle konnte nicht gefunden werden. Alarm mask"). The modifications will be saved or restored one menu level higher in "SNMP CONFIGURATION".
- 3. DTS Location information, which is displayed in SNMP management tool.
- 4. Contact information, which is displayed in SNMP management tool.
- 5. Configuration of SNMP V1 / V2 c (specific settings). See chapter "6.5.24 SNMP V1 / V2c"
- 6. Configuration of SNMP V3 (specific settings). See chapter "6.5.25 SNMP V3"
- Notice: Each configuration change leads to a restart of the DTS SNMP Agent.

6.5.24 SNMP V1 / V2c

```
P10.241.0.5 - PuTTY

DTS 4148.grandmaster Moser-Baer AG

SNMF V1/V2c CONFIGURATION
1 Readonly community string romobatime
2 Read/write community string rwmobatime
98 Return and save
99 Return and discard changes
Enter desired menu number>
```

- 1. Community string for **read only** (Group membership for GET). Standard: *romobatime*.
- 2. Community string for **read/write** (Group membership for GET/PUT). Standard: *rwmobatime.*

Notice: Each configuration change leads to a restart of the DTS SNMP Agent.



6.5.25 SNMP V3

🛃 10.241.0.5 - PuTTY	
DTS 4148.grandmaster Moser-Baer AG	
<pre>SNMP V3 CONFIGURATION 1 User 1 configuration (dtsUser1) 2 User 2 configuration (dtsUser2) 3 Access 1 configuration (viewDTS1) 4 Access 2 configuration (viewDTS2)</pre>	
99 Return	
Enter desired menu number>	<u> </u>

1. - 2. Configuration of user-defined SNMP accounts dtsUser1 and dtsUser2
3. - 4. Configuration of user-defined SNMP access rights viewDTS1 and viewDTS2

Each configuration change leads to a restart of the DTS SNMP Agent. Notice:

User configuration SNMP V3:

🛃 10.241.0.5 - PuTTY		
	1	
dtsUser1 mobatime noauth _all_ viewDTS1		
	mobatime noauth _all_	

1. Password for authentication (MD5) and privacy (DES). 8 - 40 characters.

2.	Minimal security level:	1=noauth (no authentication) 2=auth (only authentication) 3=priv (authentication and privacy)
3.	SNMP read access:	0=none (no access) 1=all (full access) 2=DTS info (only DTS specific information)

3=user defined 1 (viewDTS1) 4=user defined 2 (viewDTS2)
4. SNMP write access 0=none (no access) 1=all (full access) 2=DTS info (only DTS specific information) 3=user defined 1 (viewDTS1) 4=user defined 2 (viewDTS2)

Notice: Each configuration change leads to a restart of the DTS SNMP Agent.

Access configuration SNMP V3:

🚰 10.241.0.5 - PuTTY		<u>- 0 ×</u>
DTS 4148.grandmaster Moser-Baer AG		-
SNMP V3 ACCESS CONFIGURATION 1 Include OID 1 2 Include OID 2 3 Include OID 3 4 Exclude OID 1 5 Exclude OID 2 6 Exclude OID 3	<pre>viewDTS1 .1.3.6.1.4.1.8072 .1.3.6.1.4.1.2021 .1.3.6.1.4.1.13842.4 .2 .2 .2 .2</pre>	
98 Return and save 99 Return and discard changes		
Enter desired menu number>		T

- 1. 3. Include View path, form: .1.3..6.1.4.1.13842.4 (e.g. DTS) or .iso (complete SNMP ISO path).
- 4. 6. Exclude View path: analogue include.

Notice: Each configuration change leads to a restart of the DTS SNMP Agent.

6.5.26 Time zone selection

² 10.241.0.5 - PuTTY		_ U ×
DTS 4148.grandmaster Moser-Baer AG		-
* 02: [+1] Brussel 0 04: [+2] Bucharest 0 06: [+2] Amman 0 08: [+3] Kuwait 0 10: [0] UTC 1 12: [+4.5] Kabul 1 14: [+5] Tashkent 1	Page 1 1: [0] London 3: [+2] Athens 5: [+2] Cairo 7: [0] UTC 9: [-1] Cape Verde 1: [+4] Abu Dhabi 3: [-8] Pitcairn Is. 5: [+5.5] Mumbai 7: [+7] Bangkok	
18: [+8] Singapore 1 Enter requested time zone Press enter for next part, ESC to leave	9: [+9] Tokyo re>	

Display of all the DTS 4148 time zones (100) over several pages. The pages can be scrolled through with ENTER.

A time zone can be selected on the current page by entering a time zone number.

Only one time zone can be selected.

A * indicates the selected time zone.

Press ESC to leave the page. The modifications will be saved or restored one menu level higher.

6.6 Maintenance menu

DT	S 4148.grandmaster Moser-Baer AG	
МА	INTENANCE	
1	Update software (FTP)	
2	Update software (USB)	
3	Backup configuration and log to USB	
4	Backup configuration local	
5	Restore configuration (backup)	
6	Restore configuration (default MOBA)	
7	Restart device	
8	Copy telegram files	
99	Return	
	the designed many surplus	
En	ter desired menu number>	

 Initiating a software update (files must have been copied by FTP into the directory /ram of the DTS 4148 before). → See chapter "7 Updates". The command always leads to a restart of the DTS 4148 (even if no files were copied for update).



Notice: Possibly save configuration first.

Initiate a software update (files must first be put on to a USB stick in the DTS 4148). → See chapter "7 Updates". The command always leads to a restart of the DTS 4148 (even if no files were copied for update)



Notice: Possibly save configuration first.

- 3. Save the entire configuration (incl. telegram files) and the log files on a USB stick . Also generates a diagnosis file (dts4148system_xxxxxxxxx.log) in the directory /ram which is also copied on to the USB stick or which can be downloaded per FTP (only for support).
- 4. Backup the entire configuration locally (→ file dts4148.conf.bkp is created).
- 5. Restore the entire configuration from a backup stored locally.
- 6. Restore the entire configuration to factory settings.
- 7. Restart DTS 4148.
- 8. Copy telegram files onto the DTS 4148.
 → See chapter "7.10 Copying Telegram files to the DTS 4148.grandmaster".

See also chapter "7 Updates".

7 Updates

7.1 Updating images with MOBA-NMS

Steps for updating images using MOBA-NMS:

- 1. Select DTS device(s) in the device view.
- 2. Menu 'Edit' → 'Commands' → Select 'Firmware Update...'.
- 3. Enter the path to the file 'dtscheck.md5' or select it using the 'Browse...' button.
- 4. Enter further paths to images or select them using the 'Browse...' button.
- 5. Optionally: Check the box 'Backup device(s) configuration before update' and enter the destination directory for the backup file(s). If a destination folder is selected, the whole device configuration will be saved before the backup. Additionally, if the image 'dts4148cfg.img' is written too, the saved configuration can be automatically restored after the update. For this, check the box 'restore configuration after update'.
- 6. By clicking the 'OK' button, the update is initiated.
- **Important:** The update procedure (item 6) can take some time (<5 min.) and may not be interrupted under any circumstances. In case of an interruption, the software on the DTS 4148 is destroyed and can only be repaired in the factory.

7.2 Updating images with FTP

Possible images are: u-bootDTS4148, rootfsDTS4148.img, uImageDTS4148, dts4148app.img, dts4148cfg.img. Additionally the file dtscheck.md5 must exist. → all file names are case-sensitive.

Steps for updating images:

- Connect a FTP client software to the DTS 4148 e.g. with Internet Explorer enter: *ftp://dts@[IP address]*) (as user dts). See also chapter
- 2. If an update of the image dtscfg.img is made, the configuration of the DTS 4148 and the telegram files are overwritten. In order to store the configuration, the file dts4148.conf from the directory /etc and any possible telegram files must be saved from the directory /var/local/dts. After the update, the file can again be written on the DTS 4148 in accordance with chapter "7.3 Updating applications or configurations with FTP".
- 3. Change to the directory /ram.
- 4. Copy the image into the directory /ram.
- 5. Close FTP connection.
- The update procedure can be started on DTS 4148 by selecting the menu '3. Maintenance' → '1. Update software (FTP)' and press ENTER. The message "Update in progress" appears and at the same time, "Please wait!>" is shown in the command line. All images are copied. The DTS 4148 is automatically restarted on completion of the update.

The Telnet or SSH session has to be restarted.

Notice:

The update procedure (point 6) may take some time depending on the type and number of images (<5 min) and must not be interrupted under any circumstances. If interrupted, the software on the DTS 4148 will be destroyed and the DTS 4148 has to be returned to the manufacturer for repairing.

Starting up after an update can also take some minutes (<10 min), or it can result in an additional restart, as the file systems have to be checked first.

To eliminate any mistakes during update procedure, the versions should be verified after the update.

7.3 Updating applications or configurations with FTP

To update individual files such as, e.g. dts4148app, dts4148menu, ntpd, dts4148mod.ko, dts4148.conf, etc. on the DTS 4148, the following steps are carried out \rightarrow all file names are case-sensitive:

- Connect a FTP client software to the DTS 4148 e.g. with Internet Explorer enter: ftp://dts@[IP address]) (as user dts). See also chapter 7.6 FTP connection
- 2. Change to the directory /ram.
- 3. Copy all the files to be updated into the directory /ram.
- 4. Close FTP connection.
- 5. The update procedure can be started on DTS 4148 by selecting the menu '3. Maintenance' → '1. Update software (FTP)' and press ENTER. The message "Update in progress" appears and at the same time, "Please wait!>" is shown in the command line. All images are copied. The DTS 4148 is automatically restarted on completion of the update. The Telnet or SSH session has to be restarted.

Notice: The update procedure (point 5) may take longer time depending on the type and number of images (<5 min) and must not be interrupted under any circumstances. If interrupted, the software on the DTS 4148 will be destroyed and the DTS 4148 has to be returned to the manufacturer for repairing.

To eliminate any mistakes during update procedure, the versions should be verified after the update.

7.4 Updating images via USB

Possible images are: u-bootDTS4148, rootfsDTS4148.img, ulmageDTS4148, dts4148app.img, dts4148cfg.img. Additionally the file dtscheck.md5 must exist. → all file names are case-sensitive.

Steps for updating images:

- 1. Copy images to the USB stick
- 2. Plug the stick in the DTS 4148
- 3. If an update of the <u>dtscfg.img</u> image is made, the configuration of the DTS 4148 and the telegram files are overwritten. In order to store the configuration, the file *dts4148.conf* from the directory /etc and any possible telegram files must be saved from the directory /var/local/dts. After the update, the file can again be written on the DTS 4148 in accordance with chapter "7.3 Updating applications or configurations with FTP".

- 4. The update procedure can be started on DTS 4148 by selecting the menu '3. Maintenance' → '2. Update software (USB)' and press ENTER. The message "Update in progress" appears and at the same time, "Please wait!>" is shown in the command line. All images are copied. The DTS 4148 is automatically restarted on completion of the update. The Telnet or SSH session has to be restarted.
- 5. As soon as the DTS 4148 is restarted, remove the USB stick.
- **Notice:** The update procedure (point 4) may take longer time depending on the type and number of images (<5 min) and must not be interrupted under any circumstances. If interrupted, the software on the DTS 4148 will be destroyed and has to be returned to the manufacturer for repairing.

Starting up after an update can also take some minutes (<10 min), or it can result in an additional restart, as the file systems have to be checked first .

To eliminate any mistakes during update procedure, the versions should be verified after the update.

7.5 Updating applications or configurations via USB

To update individual files, e.g. dts4148app, dts4148menu, ntpd, dts4148mod.ko, dts4148.conf, etc. on the DTS 4148, the following steps are carried out → all file names are case-sensitive, all names with 4148:

- 1. Copy applications (or configuration) to the USB stick
- 2. Plug the stick in the DTS 4148
- The update procedure can be started on DTS 4148 by selecting the menu '3. Maintenance' → '2. Update software (USB)' and press ENTER. The message "Update in progress" appears and at the same time, "Please wait!>" is shown in the command line. All applications are copied. The DTS 4148 is automatically restarted on completion of the update. The Telnet or SSH session has to be restarted.
- 4. As soon as the DTS 4148 is restarted, remove the USB stick.
- **Notice:** The update procedure (point 3) may take longer time depending on the type and number of images (<5 min) and must not be interrupted under any circumstances. If interrupted, the software on the DTS 4148 will be destroyed and the DTS 4148 has to be returned to the manufacturer for repair.

To eliminate any mistakes during the update procedure, the versions should be verified after the update.



Important: USB stick recognition:

After removing the USB stick, wait approx. 1 min. before re-inserting the it again. Otherwise it can be, that the USB stick is not recognized.

7.6 FTP connection

Establish anonymous connection: *ftp://"IP address of DTS 4148"* to directly reach the sub-directory /**ram**, e.g. Explorer *ftp://10.241.0.5*

Establish connection as/with a user: *ftp://dts@"IP address of DTS 4148".* e.g. with Internet Explorer enter: *ftp://dts@10.241.0.5* Password: **dts** resp. the defined password for the menu. To directly reach the sub-directory */ram*, you can also enter *ftp://dts@10.241.0.5/ram*.

Establish connection with IPv6: The address <u>must</u> be written in brackets []: e.g. with Internet Explorer enter: *ftp://dts@[fd03:4432:4646:3454::2000]*

Notice: The file has to be copied in binary mode (not ASCII).

FTP tools

	Windows XP, 7, 8, 10	Linux (Suse, Redhat)
Integrated in the system (file manager):	Windows Explorer Start → Execute: Explorer	Konqueror / Dolphin
Programs (examples)	CuteFTP	Kbear

7.7 SFTP connection

SFTP = SSH File Transfer Protocol

SFTP tools

	Windows XP, 7, 8, 10	Linux (Suse, Redhat)
Integrated in the system (file manager):	-	Konqueror / Dolphin
Programs (examples)	WinSCP	-

7.8 SCP connection

SCP = Secure Copy Protocol

Notice: SCP connection can only be established when no menu (operation) is open.

The following error message can be ignored. There is no influence in the functionality of the operation:

```
Command 'groups' failed with termination code 127 and error message -sh: groups: not found.
```

SCP tools

	Windows XP, 7, 8, 10	Linux (Suse, Redhat)
Integrated in the system (file manager):	-	With command line
Programs (examples)	WinSCP	-

7.9 Save Configuration externally

(for backup or copy to another DTS 4148)

Save the current configuration via MOBA-NMS:

- 1. Select DTS device in the device view.
- 2. Menu 'Edit' → Select 'Backup configuration...'.
- 3. Select the elements that are to be saved. (In case of doubt, select everything)
- 4. Click button 'Next >'.
- 5. Indicate destination file by clicking the 'Browse...' button.
- 6. Optionally: enter a free backup comment. E.g. reason for the backup, use, etc. This comment will then be shown during the restoration of the backup.
- 7. By clicking the 'Finish' button, the backup is created.
- 8. At the end of the backup, an overview of the process is shown. It shows which elements were saved and which ones are not available or could not be saved.

Save the current configuration via FTP:

- 1. Connect a FTP client software to the DTS 4148 (with Internet Explorer enter: *ftp://dts@"IP address"*) (as user dts).
- 2. Change to the DTS 4148 directory /*etc*.
- 3. Save the file *dts4148.conf* (configuration) to the user PC (e.g. copy the file to the Desktop or to the directory *My Documents*).
- 4. Additionally also save possible telegram files from the directory /var/local/dts.

Save the current configuration via USB-Stick:

The whole procedure can be analogously done with an USB stick. The copy procedure to the USB stick can be started on DTS 4148 by selecting the menu '3. Maintenance' \rightarrow '3. Backup configuration and log to USB' and press ENTER. All files (including telegram files) will be copied into the root directory of the USB stick.

Copy configuration to another DTS 4148:

In order to copy the entire configuration or elements of it from a DTS device to another, the according assistant in MOBA-NMS can be used. For this, select the source device (from which the configuration shall be transferred) and start the assistant in the menu 'Edit' \rightarrow 'Transfer configuration...'. It will lead you through the individual steps.

Without MOBA-NMS, perform the procedure explained in chapter 7.3 resp. 7.5.

Notice: When copying the configuration from one DTS 4148 to an other, the IP address may have to be changed after the download by serial connection.

7.10 Copying Telegram files to the DTS 4148.grandmaster

Analogously to the previously described procedures telegram files can be copied via FTP or USB stick to the DTS 4148.

The copy procedure can be started on DTS 4148 by selecting the menu '3. Maintenance' \rightarrow '8. Copy telegram-files' and press ENTER. Afterwards, select again in the menu "6.5.4 Serial interface" and reload.

The files are stored in the directory /**var**/**local**/**dts** and can be deleted or copied via FTP.

Special case USB stick:

If the DTS recognizes the insertion of an USB stick, it is shown on the display. By pressing the red button the copy procedure can be released (analogously to the above described procedure). The button has to be pressed until the copy procedure is started.

Management with MOBA-NMS:

With MOBA-NMS, the files do not need to be copied manually via FTP or USB stick, since this is already integrated in the MOBA-NMS operation. At every file selection, the 'Change...' link can be clicked. This opens a file dialog which shows all files and allows new files to be loaded onto the device or existing ones to be deleted.

Example of a program file choice:

Program file:	haustec1.prg	•	Change

Link for opening the file dialog for editing the file list.

Notice: After the file copy procedure, the output of the telegram files are re-started (take over of the files).


Notice: The file name is limited to 8 characters before the dot, e.g. IF482Std.tel



8 Time administration

8.1 Concept of time administration

The internal master clock as well as the real-time clock runs with UTC (Universal Time Coordinated). The synchronisation inputs, the time shown on the display, as well as all outputs are linked via a time zone entry with the master clock time, i.e. all inputs and outputs can be individually allocated to a specific time zone.



Configurable time zones:

- (A) chapter 6.5.8 Time source
- (B) chapter 6.5.2 DCF output
- (C) chapter 6.5.3 DCF / Pulse / Frequency output
- (D) chapter 6.5.5 IRIG / AFNOR / DCF-FSK Output
- (E) chapter 6.5.4 Serial interface
- (F) chapter 6.5.6 NTP slave clocks / time zone server
- (G) chapter 6.5.20 General settings
- * NTP is always UTC
- ** PTP is always TAI (PTP timescale)

8.2 Time acceptance

Variants of time synchronization

• Adjusting:

After starting the DTS 4148, the time is set for a first time (from source or manually). Afterwards, the time will only be aligned with maximum adjusting speed if deviating from the source \rightarrow no time steps possible.

Configuration: see chapter "6.5.9 Time adjustment / Time-keeping"

• Setting:

Time deviations are always corrected in full immediately: Seconds are set immediately; partial seconds are corrected with 50ms/s.

Manual time set:

• The time is always set immediately. The stratum is set to 1 or pre-set to a fix stratum. If new source time information is available, the time will be adjusted again and the stratum set accordingly.

8.3 Time acceptance from an external source (DCF or GPS)

Acceptance from an external source (DCF input):

• At least 2 minutes reception (DCF-GPS) is required, before the NTP server is available.

Time source stratum = $0 \rightarrow$ stratum of the DTS 4148 = 1

Stratum normal, synchronized operation:

 The stratum value behaves as follows for synchronization from the time source: If St_fix > 0: then stratum = St_fix (particularly for manually set time) applies If St_fix = 0: then stratum = 1

Stratum in case of error:

 The stratum value behaves as follows in the case of external time source loss: If St_fix > 0: then stratum = St_fix applies If St_fix = 0: then stratum = MIN/(the summation to be strategies)/(Text 255). Otherwork applies

then stratum = MIN((t_current - t_lastsynch)/(To * 255), St_max) applies

• Adjusting the clock after identifying a leap in time:

If $St_fix > 0$:	then stratum = St_fix applies
If Tst > 0 AND St_fix = 0:	then stratum = MIN(Tdiff/Tst, St_max) applies
If Tst = 0 AND St_fix = 0:	then stratum = 1 (auto) applies

Legend:

To:	Stratum TO <0-16>, Stratum error timeout time 1-999 [h], for loss
	of the external source
St_fix:	015, configurable stratum, 0 = auto
St_max:	116, configurable stratum, 0 = auto
t_current [s]:	current time
t_lastsynch [s]:	time of the last synchronization
Tst:	Offset per stratum, 040'000 [ms], parameter time deviation for
Tdiff:	stratum alteration by 1 current time difference in ms

8.4 Time acceptance from external AFNOR-A/C, IRIG-B12x source

The stratum value is calculated same as with DCF/GPS synchronization (chapter 8.3). As IRIG-B120 to 123 time codes do not provide information about the current year, the DTS 4148 has to be synchronized first from another time source or the date has to be set manually. The DCF input and the IRIG input cannot be used at the same time for the synchronization (redundant time source with DCF and IRIG synchronization is not possible).

AFNOR and IRIG-B126 contains the time and date information.

Attention: After more than 5 days without power, the DTS 4148 loses the date information. When synchronized with IRIG-B120 to 123 it has to be set again manually.

8.5 Time acceptance from NTP

Acceptance:

 As NTP RFC 1305, RFC 5905 (www.ntp.org) (see http://ntp.isc.org/bin/view/Servers/WebHome for internet-server)

Stratum in normal, synchronized operation:

 Stratum value of DTS is always one step higher than that of the current NTP time server

Stratum in case of an error

• As NTP RFC 1305, RFC 5905 (www.ntp.org)

8.6 NTP as backup

If DTS 4148 is synchronized with a DCF or GPS source, the NTP can be used as redundancy source. This function is active, as soon as at least one grandmaster is configured in menu '2. Configuration' \rightarrow '2. Time handling \rightarrow '4. NTP server').

Stratum in normal, synchronized operation:

• Equal Stratum value "Time Acceptance from an external source (DCF or GPS)"

Behavior in case of an error:

Failure of primary Source:

 "St. est":Means: Expected NTP Stratum of the NTP sources
 "St. est" = MAX(Stratum NTP candidates)
 → Means: "St. est" contains the stratum value of the poorest NTP source.
 If internal Stratum > "St. est" + 1, then change to NTP as source takes place

(internal stratum is one step higher than that of the poorest available NTP source).

• As soon as the primary source is available again, the changes are set back.

8.7 Time server

- NTP v4 (compatible with v3) as per RFC 1305, RFC 5905 (port 123)
- SNTP (UDP), RFC 2030 (port 123)
- PTP (UDP), IEEE 1588-2008 (V2) (ports 319 and 320)
- TIME (TCP/UDP), RFC 868 (port 37)
- DAYTIME (TCP/UDP), RFC 867 (port 13)

8.8 Time accuracy, time-keeping

See appendix H Technical data.

8.9 Leap second

The announcement of the switching second is put out by DCF and NTP* each time 1 hour before the defined time.

*The announcement is only sent via NTP if a DCF or IRIG source is active. If only one NTP source is configured, the state of this source is passed on.

Automatic mode

In the automatic mode, the source (DCF or NTP) is checked for a possible announcement during 1 hour prior to the moment of a possible leap second. If the announcement is recognized, it is passed through the NTP and DCF outputs and the leap second is inserted.

The leap second can be inserted at 2 moments per year: 00:00:00 1.1. or 00:00:00 1.7. each in UTC. Whether a leap second is inserted is decided by the organization IERS (http://www.iers.org) each time up to half a year in advance.

8.10 NTP Authentication

NTP provides two variants for authentication in version 4:

- NTP symmetric keys (i.e. symmetric keys)
- NTP autokeys

NTP authentication assures a correct time source and prevents manipulation of NTP information. NTP data itself is, however, not encoded.

8.10.1 NTP symmetric keys

A 32-bit key ID and a cryptographic 64/128-bit check sum of the packet is attached to each NTP IP packet.

The following algorithms are used for this purpose:

- Data Encryption Standard (DES) (partly restricted in North America and no longer integrated into new NTP variants (>V4.2))
- Message Digest (MD5)

The DTS 4148 only supports the MD5 procedure.

The receiving NTP service calculates the check sum with an algorithm and compares it with the one contained in the packet. Both NTP services must have the same encryption key and the same corresponding key ID for this purpose. Packets with a wrong key or wrong check sum will not be used for synchronization . The DTS 4148 must be correspondingly configured to be able to use NTP authentication (chapter 6.5.11 NTP server). The NTP service of the other equipment (e.g. server, PC...) must also be configured. In the case of standard NTP, this occurs via the ntp.conf file:

```
# path for key file
keys /etc/ntp/ntp.keys
trustedkey 1 2 3 4 5 6# define trusted keys
requestkey 4 # key (7) for accessing server variables
controlkey 5 # key (6) for accessing server variables
```

server ntp1.test.org key 2
server ntp2.test.org key 6
server 192.168.23.5 key 3

The description of the ntp.conf file can be accessed via the corresponding man-page, or consulted at http://www.eecis.udel.edu/~mills/ntp/html/authopt.html

The authentication mode is automatically activated when a key is used and the paths for the keys have been correspondingly configured.

trustedkey defines all keys currently permitted

requestkey defines the key for the ntpq help tool.

controlkey defines the key for the ntpdc help tool.

The keys are located in the ntp.keys file defined with keys. This has the following format:

1 M TestTest 2 M df2ab658 15 M I_see! 498 M NTPv4.98

The key ID is in the first column of the file, the format of the keys in the second defined column, and the key itself in the third. There are four key formats, however, nowadays only the MD5 is still used \rightarrow M. The letter M is no longer written for new NTP variants (>V4.2) and is only necessary for backwards compatibility.

The signs ' ', '#', '\t', '\n' and '\0' are not used in the MD5 ASCII key! Key 0 is reserved for special purposes and should therefore not be used here.

ntp.keys: man page for ntp.keys to be noted (check the internet)

8.10.2 NTP Autokey

The validity of the time received to the NTP clients is assured by symmetric keys. For a higher degree of certainty, exchanging the keys used regularly is, however, necessary to obtain protection, e.g. from replay attacks (i.e. attacks in which recorded network traffic is simply played back).

The autokey procedure was introduced as the exchange is very involved in a large network. A combination of group keys and public keys enables all NTP clients to check the validity of the time information which they receive from servers in their own autokey group.

NTP Autokey is relatively complex in its use and studying the functionality is definitely necessary beforehand.

Autokey is described at *http://www.cis.udel.edu/~mills/proto.html* or on the NTP homepage *http://www.ntp.org*.

Autokey is currently defined in an IETF draft. http://www.ietf.org/internet-drafts/draft-ietf-ntp-autokey-04.txt

The configuration of Autokey is explained in *http://support.ntp.org/bin/view/Support/ConfiguringAutokey* or in *http://www.ntp.org/ntpfaq/NTP-s-config-adv.htm#S-CONFIG-ADV-AUTH.*

-PTP according to IEEE STD 1588-2008

-V2 only, no V1

-P2P, E2E

-IPv4, IPv6, Layer2, UDP, Multicast according to definition IEEE 1588

-master only (active or passive)

-If both interfaces are used, the DTS 4148 becomes a boundary clock with 2 master ports according to IEEE 1588.

-"2 step" procedure only: synch. message with follow-up message

-availability of management messages limited: requests only

-profiles: IEEE 1588 annex J, default profile

-no specific PTP SNMP MIB


8.12 Redundant operation of 2 DTS 4148.grandmasters

For redundant operation two DTS 4148 devices are synchronized via optical fibers. For this purpose, a mini GBIC module is plugged into both devices and connected via optical fibers (see Appendix H Technical data):



mini GBIC module

Both devices have a GPS receiver in redundant operation. Both devices are configured for the redundant mode, but are basically equal and work out the master/slave role among themselves. The slave is always synchronized to the master in operation. The slave supervises the system time on the basis of its own GPS time and generates an error message, should the time difference amount exceed the configurable value of n milliseconds.



- Starting the devices with fiber optic connection The devices work out among themselves which is the master (normally the one synchronized first)
- Starting the devices without fiber optic connection The devices do not send out any time information until there is an LWL connection, or the devices are reconfigured.
- The slave synchronizes to the master. Whereby stratum/slave = stratum/master +1 The time of the slave is always set immediately to the master time (no fine adjustment).

- In case of loss of the master GPS, the master stratum increases on the basis of the configurable parameters up to the maximum stratum. The slave follows, i.e. the slave stratum is always 1 higher. The slave takes over the master role from a configurable stratum value (if the status of the slave is better than that of the master) and synchronizes to its own GPS. The previous master becomes the slave. This distribution of roles remains until the new master loses GPS synchronization.
- In the case of a loss of the master, the slave takes over the master function.
- If the former master is working again, it takes over the actual time of the current master and remains in slave mode.
- In the case of a fiber optic connection loss, the slave checks the status of the master over the network and remains in slave mode as long as the master is accessible and is working normally. If the master is no longer accessible or has a worse status, the slave takes over the master function.

<u>NTP</u>

The NTP clients select the server with the lower stratum.

<u>PTP</u>

-If both interfaces are used, the DTS 4148 becomes a boundary clock with 2 master ports according to IEEE 1588.

-Redundancy (2 Master) via opt. link; both send out (DTS Master is active, DTS Slave is passive)

-Clients use BMC (Best Master Clock algorithm)

DCF coded (fiber optic output)

No redundancy

2 LAN Mode

The two redundant DTS 4148 are not located in the same network. The role decision (master, slave) takes place exclusively via opt. link.

RTC:

RTC is to be deactivated for the redundant mode.

9.1 General

The SNMP version V2c or V3 for Get, Put and Notification (Trap) is used.

A full SNMP agent is implemented on the DTS (MIB II, DTS4148).

For SNMP V2c, following standard *Communities* are used:

Read only :	romobatime
Read/Write:	rwmobatime
Trap:	trapmobatime

For SNMP V3, following standard User I Passwords are used: dtsUser1 mobatime dtsUser2 mobatime dtsInfo mobatime (not changeable, read only)

DtsUser1 and dtsUser2 have full read/write access on all objects. With SNMP V3 rules, access can be reduced. Changes of the rules can only be modified over the DTS menu but not via SNMP.

SNMP V3 agent supports user validation (authentication MD5) and encoding (encryption DES).

MIB II values like sysDescr, sysContact, sysName, or sysLocation can only be modified over the DTS menu but not via SNMP.

The following MIB definitions are used:

SNMPv2-SMI, SNMPv2-MIB, SNMPv2-CONF, SNMPv2-TC, SNMPv2-TM, SNMP-FRAMEWORK-MIB, SNMP-MPD-MIB, SNMP-NOTIFICATION-MIB, SNMP-TARGET-MIB, SNMP-USER-BASED-SM-MIB, SNMP-VIEW-BASED-ACM-MIB, RFC1213-MIB, IF-MIB, IP-MIB, IP-FORWARD-MIB, TCP-MIB, UDP-MIB, HOST-RESOURCES-MIB, HOST-RESOURCES-TYPES, DISMAN-EVENT-MIB, NOTIFICATION-LOG-MIB, UCD-SNMP-MIB, NET-SNMP-MIB, NET-SNMP-TC

SNMP V2c, V3: DTS-COMMON (File: DTS-COMMON-MIB.TXT) General DTS definition, always required DTS4148 (DTS4148-MIB.TXT) Device-specific DTS definitions

The MIB files can be copied from the DTS 4148 with FTP (For FTP use, see chapter "7.6 FTP connection"):

DTS-MIB: /etc/snmp/mibs/ Standard MIBS: /usr/share/snmp/mibs/

9.2 Device configuration with SNMP

If one or several variables are set in a configuration group with *Put*, the variable *dts4148????ConfigCmd* must be set at the end to 1 in the corresponding group. The values of the entire configuration group are assumed from the DTS with this command (1=Save).

As long as the accept command has not been set, the changed variables can be restored to the old values by setting the *dts4148????ConfigCmd* variable to 2 (2=undo, restore).

After sending the accept command, a dts4148ConfigChanged Notification is sent.

The definitions of the available variables can be taken from the MIB files.

Example:

Management-System		DTS
Put dts4148FTPMode=1	\rightarrow	Variable is set to 1 internally
Put dts4148NetServicesConfigCmd=1	\rightarrow	Configuration group is assumed
	←	Sends dts4148ConfigChanged Notification

9.3 DTS subagent SNMP notification

Protocol: SNMPv2c Notification

For *Notifications* to be sent out, SNMP must be switched on. In addition, at least one receiver system must be configured.

9.3.1 Startup

[dts4148StartUp]

[dts4148Shutdown]

with the new time dts4148NetConfigChangedTime

Sent out when the subagent for the DTS is started.

This *Notification* is always sent out, as soon as SNMP is activated and a destination address is configured.

9.3.2 Shutdown

Sent out when the subagent for the DTS is stopped.

This *Notification* is always sent out, as soon as SNMP is activated and a destination address is configured.

9.3.3 Status changed

[dts4148StatusChanged]

Sent out when the subagent detects a status change in the DTS application process. The following variables are monitored for changes:

dts4148SysStatus, dts4148NTPTInfoCurrentSource, dts4148SysStratum

This *Notification* is always sent out, as soon as SNMP is activated, and a destination address is configured.

Field	Туре	Size	Description	Example
dts4148SysStatus	Unsigned Int	4 Bytes	Contains the internal system status	66309
dts4148SysOffset	Integer	4 Bytes	Actual time offset of the system [us]	-1523 → -1.523ms
dts4148SysTimeSource	Byte	1 Byte	Actual time source	2
dts4148SysStratum	Byte	1 Byte	Actual system stratum level	1

The Notification sent out contains the following data:

9.3.4 Configuration changed

[dts4148ConfigChanged]

Sent out when the subagent detects a configuration change in the DTS application processes.

This *Notification* is always sent out, as soon as SNMP is activated and a destination address is configured.

The *Notification* sent out contains the following data:

Field	Туре	Size	Group
dts4148SysConfigChangedTime	TimeTicks	4 Bytes	dts4148System
dts4148NetworkIf0ConfigChangedTime	TimeTicks	4 Bytes	dts4148NetworkIf0
dts4148NetworkIf1ConfigChangedTime	TimeTicks	4 Bytes	dts4148NetworkIf1
dts4148NetConfigChangedTime	TimeTicks	4 Bytes	dts4148Network
dts4148NetServicesConfigChangedTime	TimeTicks	4 Bytes	dts4148NetServices
dts4148TSConfigChangedTime	TimeTicks	4 Bytes	dts4148TimeSource
dts4148RedOpConfigChangedTime	TimeTicks	4 Bytes	dts4148TimeRedundantOp
dts4148NTPConfigChangedTime	TimeTicks	4 Bytes	dts4148TimeNTPServer
dts4148OutMainDCFConfigChangedTime	TimeTicks	4 Bytes	dts4148OutMainDCF
dts4148OutLineDCFPulseFREQConfigChangedTime	TimeTicks	4 Bytes	dts4148OutLineDCFPulseFREQ
dts4148OutLineSerialConfigChangedTime	TimeTicks	4 Bytes	dts4148OutLineSerial
dts4148OutLineIRIGConfigChangedTime	TimeTicks	4 Bytes	dts4148OutLineIRIG
dts4148OutLineTZServerConfigChangedTime	TimeTicks	4 Bytes	dts4148OutLineTZServer
dts4148RelayConfigChangedTime	TimeTicks	4 Bytes	dts4148AlarmRelayConfig
dts4148MailConfigChangedTime	TimeTicks	4 Bytes	dts4148AlarmMailConfig
dts4148SnmpConfigChangedTime	TimeTicks	4 Bytes	dts4148SnmpConfig
dts4148SnmpV3ConfigChangedTime	TimeTicks	4 Bytes	dts4148SnmpV3

The *ConfigChangedTime* variables show the time of the last change of the relevant configuration group as TimeTicks value in 1/100th seconds. The management system can decide on the basis of these time values, which configurations need to be reloaded.

The groups and their parameters are listed in appendix "G Parameters".

9.3.5 Alive Notification

Sent out in a configurable interval.

This *Notification* is always sent out, as soon as SNMP and the alarm traps are activated and a destination address is configured.

Field	Туре	Size	Description	Example
dts4148SysStatus	Unsigned Int	4 Bytes	Contains the internal system status	66309
dts4148SysAlarms	Byte Array	8 Bytes	64 Bit Alarm flags 1.Byte Bit 07 2.Byte Bit 815 :: 8.Byte Bit 5663	FFF870FF.FFFFFFF 5.Byte 2.Byte 1.Byte

9.3.6 Alarm Notification

[dts4148Alarm]

Sent out if alarm status changes, i.e. *Notification* is sent out when an alarm flag is set or deleted.

This *Notification* is always sent out, as soon as SNMP and the alarm traps are activated and a destination address is configured.

Field	Туре	Size	Description	Example
dts4148TrapAlMsgErrorNr	Byte	1 Byte	No. of the alarm bit (063)	3
dts4148TrapAIMsgErrorState	Byte	1 Byte	0 = alarm bit was deleted 1 = alarm bit was set	1
dts4148TrapAIMsgErrorTime	Unsigned Int	4 Bytes	PC-time in seconds since 01.01.1970 00:00:00	946684805
dts4148TrapAIMsgErrorText	Text	59 Bytes	Error text	Failure supply 1

The Notification sent out contains the following data:

10 Power supply alternatives

The DTS 4148 permits 2 different power supply alternatives:




DC power supply with 24VDC +20% / -10% to "DC in 1" or "DC in 2"
 Notice: In the menu: '2 Configuration' → '4 General' → '3 Power' must be set to '0=single'.

2. Redundant power supply: Supply1: Supply2: DC in 1 DC in 2

Supply is checked once per minute for correct functioning. The alarm 'loss of power 1' or 'loss of power 2' is set in case of error.


Notice: In the menu: '2 Configuration' \rightarrow '4 General' \rightarrow '3 Power' must be set to '1=redundant'.

Block diagram of power supply:



A Connection diagrams

A.1 Front connections



LAN 1 connection:

Plug: RJ45 Interface: Ethernet, 10/100Mbit half- or full duplex Use only shielded cables!

LAN 2 connection:

Plug: RJ45 Interface: Ethernet, 10/100Mbit half- or full duplex Use only shielded cables!

Notice: If only one LAN interface is used, it always has to be LAN 1!


USB connection:

Plug:

USB host

Notice: Only permitted for operations with a USB stick!


A.2 Connections (rear view)



DTS 4148 connections

For technical data, see appendix "H Technical data".


Clamp	Connection	Description
Ð	Earth connection	
1	DC in 1 power supply +	Input for external DC supply
2	DC in 1 power supply GND	Ground
3	DC in 2 power supply +	Input for external DC supply
4	DC in 2 power supply GND	Ground
5	Alarm relay	Alarm contact, open when alarm is active
6	Alarm relay	Max. load: 30 W (30 VDC or 1A) or 60 VA (60 VAC or 1A)
7	Alarm input +	Alarm input:
8	Alarm input -	18-36VDC, max. consumption 6mA DC, close contact. Voltage level "high" (24V available) or external contact closed → configurable: alarm or no alarm. Length of connection max. 3m.
IRIG-In	BNC	AFNOR-A/C, IRIG-B12x synchronization input
IRIG 12x Channel 1	BNC: IRIG-B12x output	AFNOR-A/C, IRIG-B1xx and DCF-FSK output for IRIG line 1
DTS extension	DTS extension	DTS extension bus



185 232
:32
232
232
y output
urrent
output
urrent loop
or DCF
2


A.3 Plug-in spring terminals

Multiple contact strip 100% protected against wrong plug; WAGO CAGE CLAMP®-connection Cross section of 0,08 mm² to 1,5 mm² (from AWG 28 to AWG 14) Voltage CSA 300 V / current CSA 10 A Rated voltage: EN 250 V Rated surge voltage: 2,5 kV Nominal current: 10 A Strip length: 7 mm (0,28 in)




Pulled off spring terminal with operation tool: 2 operation tools are delivered with the accessory bag.

A.4 Connection GPS 4500, DCF 450 or GNSS 3000



GNSS 3000 according to manual Bx-800813 chap. 9.2 Connection schematics DCF current

A.5 IRIG-B00x Digital Output TTL connection



B Time zone table

No.	City / State	UTC Offset	DST	Standard \rightarrow DST	$DST \rightarrow Standard$
00	UTC (GMT), Monrovia	0	No		
01	London, Dublin, Lisbon	0	Yes	Last Sun. Mar. (01:00)	Last Sun. Oct. (02:00)
02	Brussels, Amsterdam, Berlin, Bern, Copenhagen, Madrid, Oslo, Paris, Rome, Stockholm, Vienna, Belgrade, Bratislava, Budapest, Ljubljana, Prague, Sarajevo, Warsaw, Zagreb	+1	Yes	Last Sun. Mar. (02:00)	Last Sun. Oct. (03:00)
03	Athens, Helsinki, Riga, Tallinn, Sofia, Vilnius	+2	Yes	Last Sun. Mar. (03:00)	Last Sun. Oct. (04:00)
04	Bucharest	+2	Yes	Last Sun. Mar. (03:00)	Last Sun. Oct. (04:00)
05	Pretoria, Harare, Kaliningrad	+2	No		
06	Amman	+2	Yes	Last Thu. Mar. (23:59)	Last Fri. Oct. (01:00)
07	UTC (GMT)	0	No		
08	Istanbul, Kuwait City, Minsk, Moscow, Saint Petersburg, Volgograd	+3	No		
09	Praia, Cape Verde	-1	No		
10	UTC (GMT)	0	No		
11	Abu Dhabi, Muscat, Tbilisi, Samara	+4	No		
12	Kabul	+4.5	No		
13	Adamstown (Pitcairn Is.)	-8	No		
14	Tashkent, Islamabad, Karachi, Yekaterinburg	+5	No		
15	Mumbai, Kolkata, Chennai, New Delhi, Colombo	+5.5	No		
16	Astana, Thimphu, Dhaka, Novosibirsk	+6	No		
17	Bangkok, Hanoi, Jakarta, Krasnoyarsk	+7	No		
18	Beijing, Hong Kong, Singapore, Taipei, Irkutsk	+8	No		
19	Tokyo, Seoul, Yakutsk	+9	No		
20	Gambier Island	-9	No	-	-
21	South Australia: Adelaide	+9.5	Yes	1 st Sun. Oct (02:00)	1 st Sun. Apr. (03:00)
22	Northern Territory: Darwin	+9.5	No		
23	Brisbane, Guam, Port Moresby, Vladivostok	+10	No		
24	Sydney, Canberra, Melbourne, Tasmania: Hobart	+10	Yes	1 st Sun. Oct. (02.00)	1 st Sun. Apr. (03:00)
25	UTC (GMT)	0	No		
26	UTC (GMT)	0	No		
27	Honiara (Solomon Is.), Magadan, Noumea (New Caledonia)	+11	No		
28	Auckland, Wellington	+12	Yes	Last Sun. Sep. (02:00)	1 st Sun. Apr. (03:00)
29	Majuro (Marshall Is.), Anadyr	+12	No		
30	Azores	-1	Yes	Last Sun. Mar. (00:00)	Last Sun. Oct. (01:00)
31	Middle Atlantic	-2	No		
32	Brasilia	-3	Yes	3 rd Sun. Oct. (00:00)	3 rd Sun. Feb. (00:00)
33	Buenos Aires	-3	No	and a second	. et -
34	Newfoundland	-3.5	Yes	2 nd Sun. Mar. (02:00)	1 st Sun. Nov. (02:00)
35	Atlantic Time (Canada)	-4	Yes	2 nd Sun. Mar. (02:00)	1 st Sun. Nov. (02:00)
36	La Paz	-4	No		
37	Bogota, Lima, Quito	-5	No	nd	ot
38	New York, Eastern Time (US & Canada)	-5	Yes	2 nd Sun. Mar. (02:00)	1 st Sun. Nov. (02:00)

Time zone entries in the standard season table (version 10.2).

39	Chicago, Central Time (US & Canada)	-6	Yes	2 nd Sun. Mar. (02:00)	1 st Sun. Nov. (02:00)
40	Tegucigalpa, Honduras	-6	No		
41	Phoenix, Arizona	-7	No		
42	Denver, Mountain Time	-7	Yes	2 nd Sun. Mar. (02:00)	1 st Sun. Nov. (02:00)
43	Los Angeles, Pacific Time	-8	Yes	2 nd Sun. Mar. (02:00)	1 st Sun. Nov. (02:00)
44	Anchorage, Alaska (US)	-9	Yes	2 nd Sun. Mar. (02:00)	1 st Sun. Nov. (02:00)
45	Honolulu, Hawaii (US)	-10	No		
46	Midway Islands (US)	-11	No		
47	Mexico City, Mexico	-6	Yes	1 st Sun. Apr. (02:00)	Last Sun. Oct. (02:00)
48	Adak (Aleutian Is.)	-10	Yes	2 nd Sun. Mar. (02:00)	1 st Sun. Nov. (02:00)
49	UTC (GMT)	0	No		
50	UTC (GMT)	0	No		
51	UTC (GMT)	0	No		
52	UTC (GMT)	0	No		
53	UTC (GMT)	0	No		
54	Ittoqqortoormiit, Greenland	-1	Yes	Last Sun. Mar. (00:00)	Last Sun. Oct. (01:00)
55	Nuuk, Qaanaaq,Greenland	-3	Yes	Last Sat. Mar. (22:00)	Last Sat. Oct. (23:00)
56	Not used				
57	Western Australia: Perth	+8	No		
58	Caracas	-4.5	No		
59	CET standard time	+1	No		
60	Not used				
61	Not used				
62	Baku	+4	Yes	Last Sun. Mar. (04:00)	Last Sun. Oct. (05:00)
63	UTC (GMT)	0	No		
64	UTC (GMT)	0	No		

Time zone	City / State	UTC Offset	DST Change	Standard \rightarrow DST	$\textbf{DST} \rightarrow \textbf{Standard}$
00	UTC (GMT), Monrovia, Casablanca	0	No		
01	London, Dublin, Edinburgh, Lisbon	0	Yes	Last Sun. Mar. (01:00)	Last Sun. Oct. (02:00)
02	Brussels, Amsterdam, Berlin, Bern, Copenhagen, Madrid, Oslo, Paris, Rome, Stockholm, Vienna, Belgrade, Bratislava, Budapest, Ljubljana, Prague, Sarajevo, Warsaw, Zagreb	+1	Yes	Last Sun. Mar. (02:00)	Last Sun. Oct. (03:00)
03	Athens, Istanbul, Helsinki, Riga, Tallinn, Sofia, Vilnius	+2	Yes	Last Sun. Mar. (03:00)	Last Sun. Oct. (04:00)
04	Bucharest, Romania	+2	Yes	Last Sun. Mar. (03:00)	Last Sun. Oct. (04:00)
05	Pretoria, Harare, Kaliningrad	+2	No		
06	Amman	+2	Yes	Last Thu. Mar. (23:59)	Last Fri. Oct. (01:00)
07	UTC (GMT)	0	No		
08	Kuwait City, Minsk, Moscow, St. Petersburg, Volgograd	+3	No		
09	Praia, Cape Verde	-1	No		
10	UTC (GMT)	0	No		
11	Abu Dhabi, Muscat, Tbilisi, Samara	+4	No		
12	Kabul	+4.5	No		
13	Adamstown (Pitcairn Is.)	-8	No		

14	Tashkent, Islamabad, Karachi, Yekaterinburg	+5	No		
15	Mumbai, Calcutta, Madras, New Delhi, Colombo	+5.5	No		
16	Astana, Thimphu, Dhaka, Novosibirsk	+6	No		
17	Bangkok, Hanoi, Jakarta, Krasnoyarsk	+7	No		
18	Beijing, Chongqing, Hong kong, Singapore, Taipei, Urumqi, Irkutsk	+8	No		
19	Tokyo, Osaka, Sapporo, Seoul, Yakutsk	+9	No		
20	Gambier Island	-9	No		
21	South Australia: Adelaide	+9.5	Yes	1 st Sun. Oct (02:00)	1 st Sun. Apr. (03:00)
22	Northern Territory: Darwin	+9.5	No		
23	Brisbane, Guam, Port Moresby, Magadan, Vladivostok	+10	No		
24	Sydney, Canberra, Melbourne, Tasmania: Hobart	+10	Yes	1 st Sun. Oct. (02.00)	1 st Sun. Apr. (03:00)
25	UTC (GMT)	0	No		
26	UTC (GMT)	0	No		
27	Honiara (Solomon Is.), Noumea (New Caledonia),	+11	No		
28	Auckland, Wellington	+12	Yes	Last Sun. Sep. (02:00)	1 st Sun. Apr. (03:00)
29	Majuro (Marshall Is.), , Anadyr	+12	No		
30	Azores	-1	Yes	Last Sun. Mar. (00:00)	Last Sun. Oct. (01:00)
31	Middle Atlantic	-2	No		
32	Brasilia	-3	Yes	3 rd Sun. Oct. (00:00)	3 rd Sun. Feb. (00:00)
33	Buenos Aires, Santiago	-3	No		
34	Newfoundland, Labrador	-3.5	Yes	2 nd Sun. Mar. (02:00)	1 st Sun. Nov. (02:00)
35	Atlantic Time (Canada)	-4	Yes	2 nd Sun. Mar. (02:00)	1 st Sun. Nov. (02:00)
36	La Paz	-4	No		
37	Bogota, Lima, Quito, Easter Island, Chile	-5	No		
38	New York, Eastern Time (US & Canada)	-5	Yes	2 nd Sun. Mar. (02:00)	1 st Sun. Nov. (02:00)
39	Chicago, Central Time (US & Canada)	-6	Yes	2 nd Sun. Mar. (02:00)	1 st Sun. Nov. (02:00)
40	Tegucigalpa, Honduras	-6	No		
41	Phoenix, Arizona	-7	No	and a second	
42	Denver, Mountain Time	-7	Yes	2 nd Sun. Mar. (02:00)	1 st Sun. Nov. (02:00)
43	Los Angeles, Pacific Time	-8	Yes	2 nd Sun. Mar. (02:00)	1 st Sun. Nov. (02:00)
44	Anchorage, Alaska (US)	-9	Yes	2 nd Sun. Mar. (02:00)	1 st Sun. Nov. (02:00)
45	Honolulu, Hawaii (US)	-10	No		
46	Midway Islands (US)	-11	No	1 st Our Arr (00.00)	
47	Mexico City, Mexico	-6 10	Yes	1 st Sun. Apr. (02:00)	Last Sun. Oct. (02:00)
48 49	Adak (Aleutian Is.)	-10	Yes	2 nd Sun. Mar. (02:00)	1 st Sun. Nov. (02:00)
49 50	UTC (GMT) UTC (GMT)	0	No No		
50 51	UTC (GMT)	0	No		
51 52	UTC (GMT)	0	No		
		0	No		
52		U U	INU	1	1
53 54	UTC (GMT) Scoresbysund, Greenland			Last Sun Mar (00:00)	Last Sun Oct (01:00)
53 54 55	Scoresbysund, Greenland Nuuk, Qaanaaq, Greenland	-1 -3	Yes	Last Sun. Mar. (00:00) Last Sat. Mar. (22:00)	Last Sun. Oct. (01:00) Last Sat. Oct. (23:00)

57	Western Australia: Perth	+8	No		
58	Caracas	-4.5	No		
59	CET standard time	+1	No		
60	Santiago, Chile (old)	-4	Yes	2 nd Sun. Oct. (00:00)	2 nd Sun. Mar. (00:00)
61	Chile, Easter Island (old)	-6	Yes	2 nd Sat. Oct. (22:00)	2 nd Sat. Mar. (22:00)
62	Baku	+4	Yes	Last Sun. Mar. (04:00)	Last Sun. Oct. (05:00)
63	UTC (GMT)	0	No		
64	UTC (GMT)	0	No		

In countries where the DST switch date changes annually (e.g. Iran, Israel), the time zone has to be defined manually in the user time zone table (entries 80 - 99).

Legend:UTC:UniDST:DayDST Change:DayStandard \rightarrow DST:TimDST \rightarrow Standard:TimExample:2nd last Sun. Mar. (02:00)Switch

Important:

Universal Time Coordinate, equivalent to GMT Daylight Saving Time Daylight Saving Time changeover Time change from Standard time (Winter time) to Summer time Time change from Summer time to Standard time (Winter time)

Switch over on the penultimate Sunday in March at 02.00 hours local time.

The Time Zone Table is usually updated as needed. The current table is available for download under the following address: www.mobatime.com \rightarrow Customer Area \rightarrow Customer Support \rightarrow Support Resources \rightarrow Time Zone Table. In case your device is equipped with a newer version than shown in this manual, the current time zone settings should be checked.

Modifications / updating the time zone table:

The time zone tables are filed in the /etc/mbsn.tbl (standard table) and /etc/usersn.tbl (user table) files.

The user table can be changed with Moser-Baer AG software such as ETCW or MOBA-NMS. Using MOBA-NMS, it can be downloaded from there, otherwise, it must be copied on to the DTS 4148 in accordance with the update instructions (chapter "7.3 Updating applications or configurations with FTP").





C Alarm list

Number	Error message	Description / Action	Chap.
0	Reboot DTS	DTS 4148 restarted, no intervention required	
1	Error bit1	Not used	
2	Supply voltage too low	Power failure (internally measured) → support	
3	Power failure 1	Power failure 1 (only if redundant supply is on)	
4	Power failure 2	Power failure 2 (only if redundant supply is on)	
5	Error voltage 5V	Power failure (internally measured) → support	
6	Error voltage 2.5V	Power failure (internally measured) → support	
7	Error voltage 1.25V	Power failure (internally measured) → support	
8	Wrong time zone DCF	Check DCF configuration	6.5.2
9	Wrong time zone TC	Check TC configuration (IRIG/DCF/Impulse)	6.5.3 / 5
10	Error bit10	Not used	
11	Alarm input	Error from external device	6.5.19
12	Low voltage IRIG	Low voltage on analogue AFNOR/IRIG-B output	6.5.5
13	Error bit13	Not used	
14	Error bit14	Not used	
15	Error bit15	Not used	
16	Time source lost	Stratum too high: check time source	6.5.8
17	Failure time source TO	No time information from the selected time source within the configured timeout: Check time source. In slave mode: check link.	6.5.8
18	No valid time	20 min after starting no valid time $ ightarrow$ Check time source	
19	NTP synch. lost	Check NTP source	
20	Software trimming	Quartz error or poor source quality	
21	NTP not working	Check NTP configuration	
22	NTP backup active	Check primary source	
23	Syn only diff too large	Check synchronization and source	6.5.9
24	No mail server	Check e-mail configuration, check connection	6.5.17
25	SNMP not running	Check SNMP and trap configuration	6.5.18
26	Error bit26	Not used	
27	Error bit27	Not used	
28	Error bit28	Not used	
29	Error bit29	Not used	
30	No link (optical)	No connection via DTS link (optical link) in redundant operation. Check connection.	
31	No link (LAN)	No connection via LAN link in redundant operation. Check LAN connection.	
32	Change Slave->Master	Switch over slave -> master has occurred. Optionally, check the time source of current slave.	
33	Offset source (slave)	In slave mode only: check time sources Difference between slave and local time source too large	6.5.10
34	Fail local source	In slave mode only: check time sources	6.5.8
35	Error bit35	Not used	

36	PTP not running	Check PTP configuration	6.5.13
37	Error bit37	Not used	
38	Telefile invalid	Check telegram file: the file name is longer than 8 digits or the file type is not TEL, Tel or tel; alternatively, syntax error in telegram file	6.5.4
39	Wrong time zone serial	Check serial time zone configuration	6.5.4
40	Error bit40	Not used	
41	Error bit41	Not used	
42	Error bit42	Not used	
43	Error bit43	Not used	
44	Error bit44	Not used	
45	Error bit45	Not used	
46	Error bit46	Not used	
47	Error bit47	Not used	
48	Error bit48	Not used	
49	Error bit49	Not used	
50	Error bit50	Not used	
51	Error bit51	Not used	
52	Error bit52	Not used	
53	Error bit53	Not used	
54	Error bit54	Not used	
55	Error bit55	Not used	
56	Error bit56	Not used	
57	Error bit57	Not used	
58	Error bit58	Not used	
59	Error bit59	Not used	
60	Error bit60	Not used	
61	Error bit61	Not used	
62	Error bit62	Not used	
63	Error bit63	Not used	

D Troubleshooting

	Error	\rightarrow	\rightarrow	Solution / possible cause
1	DTS does not accept time	Does the reading change (approx. every 3 sec) Sec counter DCF in Status \rightarrow Source \rightarrow TIME SOURCE INFORMATION?	No, but 20 min. have not yet passed since the last reboot.	After new installation or powers supply failure, it may take up to 20 min. until the GPS receiver (e.g. GPS 4500) sends out valid telegrams. Wait for this time to pass.
2			No, for more than 20 minutes.	Check DCF reception LEDCheck polarity cabling to GPS.Check positioning of the GPS receiver
3		Error-Bit 23 (Syn only diff too big) in Status \rightarrow Alarm status set		The deviation to the received time is beyond the maximal allowed time correction. In the menu Configuration \rightarrow Time administration \rightarrow Time-keeping configuration \rightarrow TIME ADJUSTMENT CONFIGURATION, set the parameter synch. only offset (4) to 0 (=deactivated). The time is now adjusted independently of the deviation's extend. It is however recommended to set a limit in normal operation (default 800ms).
4		Offset to source in Status → Time→ TIME INFORMATION AND STATUS always shows the same offset		 If Error-Bit 23 set, see point 3 The deviation is that big, that offset changes cannot be seen due to the displayed resolution.
5		Configuration has just been changed		In the case of configuration changes, particularly if the time configuration is concerned, it can take several minutes for the change to appear correctly.
6	Error-Bit 16 set (<i>time source fail stratum</i>)			See 1
7	Error-Bit 17 set (<i>time source fail TO</i>)			See 1
8	Error-Bit 23 set (Syn only diff too big)			See 1
9	DTS 4148 is restarting continuously.			Check if the network settings are correct, especially the hostname and the gateway has to be configured (when no gateway is available, the own IP address can be used).
10	LAN LED (left one) is flashing orange.	No connection to the network.		Check network cabling.
11	Opening the menu via Telnet is not possible or DTS 4148. grandmaster is not or no longer reachable via network.			Check network settings in menu 2 Configuration -> 5 Network (only possible with serial connection): - IP-Address, Subnet mask and Gateway must be set correctly - Interface should be set to Auto - Check connection with "Ping" - When earlier the menu was not correctly exited (e.g. LAN cable removed), the menu can be blocked up to 15 minutes.
12	Drift (ppm) of quartz too high	The drift displayed in the menu Status \rightarrow Time \rightarrow TIME INFORMATION AND STATUS is bigger than stated in the data sheet.		 The quartz drift is measured and corrected continuously. After initial operation, it may take up to 24 hours until optimal accuracy is reached (with GPS reception). Very large temperature change (outside the specification) Time correction was carried out manually.

13	System software update	The system software can be updated using FTP client software or a USB stick (s. chapter 7 Updates). Your MOBATIME service informs you of use and necessity of a software update. If necessary, they can provide the needed firmware file.
14	Needed information to contact your MOBATIME service	Device type, part number, production number and serial number: These details are given on the adhesive type label.
		If possible provide the following files for the analysis:
		All files from the directories / var/log / and / etc / and the file: / ram/trim.log . To copy this files use FTP, e.g. Windows Explorer with ftp://[IP address], see chapter 7.6.
		If the log files cannot be copied, please read out the current software version:
		The software version can be queried in the menu 1 STATUS/9 Versions of the software
		Place and date of purchase and of commissioning of the device.
		Most comprehensive possible details of the malfunction:
		Describe the problem, possible causes, measures taken, the system environment / operating mode and configuration, etc.

E Serial Telegrams

E.1 General

A serial interface can be used in two different modes:

- Send out time of telegrams automatically (periodically)
- Receive command, send time telegram (on request)

Output modes

- Auto Periodic transmission of a time telegram or a command at the end of a second, minute, hour, or at a max. of 6 programmable times of the day, or definable output periodicity.
- on request Telegram is transmitted on request. The 'request' strings can be defined. The following requests are possible:
 - stop output
 - output telegram at once (singly)
 - output telegram at the next second (singly)
 - output every second / minute / hourly / daily or switch to auto-mode.

Telegram format

Any character sequence. Fill characters ASCII or binary.

Variable display: ASCII decimal, ASCII hexadecimal or binary. Different variables are assigned to strings in text tables (e.g. month: Jan, Feb...). Syntax for the telegram string analogous to the print command in the programming language "C". See chapter E.2 Syntax of the telegram configuration file.

Telegram time

The telegram always contains the time information for the "next" second for periodical telegram output. The telegram content is valid at the send time of the first character. The send time of the telegram can be shifted with the parameter TC (e.g. the standard IF 482 telegram valid at the end of the telegram).

The transmission time of a time telegram can be calculated with the following table. According to the transmission format set, the transmission time in ms for one character is read from the table and multiplied by the number of telegram characters:

	7 data bits						data bi	ts	
	parity	none		odd/eve	en	none		odd/eve	en
sto	p byte	1	2	1	2	1	2	1	2
		ms per	transm	ited by	e				
300	bit/s	30.00	33.33	33.33	36.67	33.33	36.67	36.67	40.00
600	bit/s	15.00	16.67	16.67	18.33	16.67	18.33	18.33	20.00
1200	bit/s	7.50	8.33	8.33	9.17	8.33	9.17	9.17	10.00
2400	bit/s	3.75	4.17	4.17	4.58	4.17	4.58	4.58	5.00
4800	bit/s	1.88	2.08	2.08	2.29	2.08	2.29	2.29	2.50
9600	bit/s	0.94	1.04	1.04	1.15	1.04	1.15	1.15	1.25
19200	bit/s	0.47	0.52	0.52	0.57	0.52	0.57	0.57	0.63
38400	bit/s	0.23	0.26	0.26	0.29	0.26	0.29	0.29	0.31

Example:

9600 Bit/s, 8 data bits, none, 1 stop bit, the telegram has 20 characters. Transmission time for the entire telegram: $20 \times 1.04 \text{ ms} = 20.8 \text{ ms}$

Name of the telegram file

The telegram file name is limited to 8 characters and its extension has to be TEL, Tel or tel, e.g. IF482Std.tel.

E.2 Syntax of the telegram configuration file

```
!TEL
      ;telegram type also !CTC or !MTS possible
;-- Start of the file (always on the first line) ------
; DEFINITIONS CONFIGURATION FILE FOR PRECISION MASTER CLOCK
;Customer:
;Date:
;Author:
;File:
; Interface:
;-- Output string -----
   the output string has a similar format to the print command in the
   programming language 'C'.
   !TS! - String with format information
   !TV! - Variables list in output sequence
   The formats and variables available can be seen below:
;
!TS!".....%d....%d...." ;String with Format information
!TV!var1,var2,..
                        ;Variables list
       ;-- Control and special characters
          " -> String beginning/end
       ;
       ;
                -> h'FE (bycc
-> \
-> new line <CR> <LF> (h'OD h'OA)
          ∖xFE
       ;
          //
          \ \
\n
       ;
       ;
       ;
                 ->
                       Format information (see below)
          8...
       ;
       ;-- Possible formats:
       ;%dn ascii-dez where n=1/2/3/4 (number of decimal points, max. 3 places received)
           e.g. variable value d'40 \implies 40 @ n=2
                                    => 040 @ n=3
       ;
       ;%X ascii-hex
                                  => 28
           e.g. variable value d'40
       ;%c char (binary)
           e.g. variable value d'40
                                  => h'28
       ;%s string (always up to, (comma) see text tables
                           Jan, => Jan
           e.g. string
       ;%b hex-output of an asciihex-string (always up to(comma)see
           text tables
       ;
                            120A, => h'12 h'0A
           e.g. string
       ;
       ;-- Possible variables:
       ;Name: Description:
                                 Range: Format:
       ;-----|------|------|------
            (Millisecond)
       ;MSE
                                   (0..999) 1W
             (Hundredth of a second) (0..99)
       ;HSE
                                              1B
             (Tenth of a second) (0..9)
       ;ZSE
                                             1B
                                  (0..59)
(0..59)
       ;SEK
                                              1B
             (Second)
       ;MIN
             (Minute)
                                              1B
       ;STD
            (12h or 24h format)
                                  (0..12)
                                  or(0..24) 1B (see !PM!)
       :
                                   (0..99)
       ;JAR
            (Year)
                                              1W
                                   or (1990..2089)
       ;
```

;

;

```
(1..31)
(1..366)
(0..6)
        :MTG
                (Day of the month)
                                                    1B
                (Day of the year)
       ;JTG
                                                  1W
1W Text table !WT!
                                                    1W
                (Day of the week)
       ;WTG
                                       (Su..Sa)
        ;DOW
                (Day of the week)
                                        (0..7)
                                                    1B !DW!
       ;KAW
                (Calendar week)
                                       (1..53)
                                                   1B (according to Din ISO 8601)
                (Month)
                                                    1W Text table !MO!
        ; MON
                                        (1..12)
        ; MNT
                (Month)
                                        (1..12)
                                                    1B
       ;AMF
                (am/pm flag)
                                        (0/1)
                                                    1W Text table !AM!
                (synchronization qual.) (0..255
       ;TMQ
                                        or A..Z) 1B (see !TQ!)
       :SAI
                (Season)
                                                    1W Text table !SA!
                                        (0..2)
                                               (Win/Sum/UTC)
       ;AKS
                (Season change
                                       (0/1)
                                                    1W Text table !AK!
                announcement)
                                     (0/1) 1W Text table !AM!
(0..3) 1W Text table !ST!
        :AMF
                (am/pm-Flag)
        ;SST
                (Season status)
                (Bit 0 = Early warning bit)
        ;
                (Bit 1 = Summer bit)
        ;
                (Synch. alarm)
       ;SYA
                                         (0/1)
                                                     1W Texttabelle !SY!
                (0:synch ok, 1: synch alarm -> Alarm Nr.16, 17 or 19)
                (Check sum) (0..255) 1B
(XOR Check sum) (0..255) 1B
        ;CHS
       ;XCH
                (XOR Check sum low nibble in ASCII) (0..9, A..F)
(XOR Check sum high nibble in ASCII) (0..9, A..F)
       ;X1C
                                                                   1В
       ;X2C
                                                                   1B
                 Definitions:
                 CHS = (Sum of all bytes up to CHS) AND h'FF
XCH = XOR link of all bytes up to CHS
        ;
        ;
               time telegram with following format (36 ASCII characters)
        ;e.g.
                "Date: tt:mm:yy Time: hh:mm:ss,mmm<CR><LF>"
        ;!TS!"Date: %d2:%s:%d2 time: %d2:%d2.%d3\n"
        ; !TV!MTG, MON, JAR, STD, MIN, SEK, MSE
                                               _____
;-- Send offset automatic telegram output ------
!SO!hh:mm:ss!
       ;Send offset from midnight 00:00:00 at periodic time
       ;output (!CS!a!...).
       ;hh = hour
                     ('00..23')
       ;mm = minute ('00..59')
;ss = second ('00..59')
               second ('00..59')
               the periodic time output should start at 06:00:00
       ;e.g.
               in each case:
       ;
       ;
               !SO!06:00:00!
       ;
;-- Interval automatic telegram output ------
!TI!p!hh:mm:ss!
       ;Interval from send offset of the periodic time output.
       ;
       ;s = every second
;m = every minute
       ;h = hourly
       ;d!hh:mm:ss! daily (max. 6 entries)
       ;p!hh:mm:ss! constant
       hh = hour ('00..23')
;mm = minute ('00..59')
;ss = second ('00..59')
       ;e.g.1 telegram output every second
               !TI!s!
       ;e.g.2 telegram output daily at 13:00:00 hours
               !TI!d!13:00:00!
       ;e.g.3: the interval of the periodic time output should be 5 seconds:
          !TI!p!00:00:05!
       ;
                                 -----
;-----
```

```
;-- Hours format -----
!PM!
      ;Hours format 12h with am/pm flag
      ;without this entry: 24h format
                          _____
;-- Synchronization mode -----
!TC!mmm!
      ;Pretiming of the telegram in ms (-90...995). To synchronize the telegram
      ;end with the second start the TC has to be set according to the telegram
      ; length and the transmission format. If TC is set, it will be performed.
      ;e.g.
            Telegram start 120ms before the start of the second:
             !TC!120!
      ;
;-----
                        _____
;-- Format time quality -----
!TO!MAX VALUE!STEP!
      ; If this entry is absent, the byte value of TMQ is
      ;outputted
      ;MAX VALUE corresponds to the byte value for A
      ;MAX VALUE-STAGE corresponds to the byte value for B
      ;MAX VALUE-2*STAGE corresponds to the byte value for C \ldots
      ;Example: A for values >=120..101
                B for values =100..81
      ;
                C for values = 80..61 ...
      ;
       ;
                !TQ!120!20!
      ;
;-- Command Strings -----
!CS!n!l!"ss..."! or !CS!n!ll!"ss..."!
      ;
      ;n = Number of the command ('2...9')
             n=2 Quit (no telegram output)
      ;
             n=3 Telegram output immediately(singly)
             n=4 Telegram output at the next second(singly)
       ;
             n=5 Telegram every second
      ;
             n=6 Telegram every minute
       ;
             n=7 Telegram hourly
              n=8 Telegram daily (-> entry: !TI!d!xx..)
       ;
             n=9 Output command (Request for external time source)
       :
              n=a Telegram output periodic according to !TI!p! and !SO!
      ;
       ;1 or 11 = Command length in bytes ('01...20')
              1=0 Command not active
      ;
       ;
      ;ss... Command string
              (max. 20 characters - must conform with 'l' or 'll')
              Wildcards can be set with the '?' sign.
              This serves as wildcard for any character.
       ;
              Characters can also be outputted in AsciiHex format:
       ;
              e.g. \xFE d.h <FE>=(h'FE) is inserted
                           d.h '\' is inserted
                    \backslash \backslash
      ;e.g. Definition of a commando for immediate telegram
             output after a request (command n=3) :
       ;
              'time<CR>' (characters ll=05)
              !CS!3!05!"time?"!
      ;
             !CS!3!5!"time\x0D"!
      ;
                       _____
;-----
;-- Area for check sum calculation-----
!CK!aa,bb!
       ;aa = first character considered (telegram start position: 0)
       ;bb = last character considered + 1
;Missing !CK! in this case the check sum is formed via the whole telegram up to the
; check sum position.
;-----
                   _____
```

```
;General info about the text tables:
   Name of the table:
                        !xx!
;
   Separating character of the entries: , (comma)
   Maximal 16 characters pro Entry
;
   Warning: , do not forget (comma) after the last entry!
;
;-- Text table day of the week (WTG Su..Sa) 7 entries ------
!WT!Sunday, Monday, Tuesday, Wednesday, Thursday, Friday, Saturday,
; -
;-- Weekday modus 1 entry -----
!DW!0..3
               ; 0 : 0 = Sunday, 1 = Monday,... 6 = Saturday
              ; 1 : 1 = Sunday, 2 = Monday,... 7 = Saturday
; 1 : 1 = Sunday, 0 = Monday,... 7 = Saturday
; 2 : 6 = Sunday, 0 = Monday,... 5 = Saturday
; 3 : 7 = Sunday, 1 = Monday,... 6 = Saturday
;-----
;-- Text table months (Jan..Dec) 12 entries -----
!MO!Jan,Feb,Mar,Apr,May,Jun,Jul,Aug,Sep,Oct,Nov,Dec,
;-- Text table season (Win, Sum, UTC) 3 entries ------
!SA!Win,Som,UTC,
               _____
;-----
; -- Text table season change announcement ------
;-- (no announcement, announcement) 2 entries
!AK!0,1,
         _____
;----
;-- Text table season status -----
;-- (0 = no announcement, winter
;--
   1 = announcement, winter
;-- 2 = no announcement, summer
;-- 3 = announcement, summer) 4 entries
!ST!A,B,C,D,
              _____
; ----
;-- Text table AM/PM flag 2 entries -----
!AM!am,pm,
          ;1.Entry AM/PM flag=0 d.h. 00:00..11:59
         ;2.Entry AM/PM flag=1 d.h. 12:00..23:59
;-- Text table synchronization alarm 2 entries -----
!SY!ok,alarm,
         ;1.Entry synchronization ok
         ;2.Entry synchronization s-failure
_____
                        _____
;-- File End ---
IEE!
; -- Name of the file (optional) ----
@nnn...
          ;nnn... File name, maximum 12 characters and a final
                 <CR>. The name can also be omitted, in this
                 case CTC 'NONAMEx.TEL'appears in the directory.
          ; IMPORTANT:
                 1) The name must stand AFTER the file end!EE!.
                  2) If a file with the same name is loaded on to the
          ;
                    CTC, such as one stored on the CTC, the stored one
          ;
                    will be OVERWRITTEN.
          ;
                 !EE!
          ;e.g.
                  @TELEDEF.TEL
          ;
                  ;last line
          ;
;-----
                           _____
```

;last line (guarantees a <CR> after the file name)

F Copyright Notice

All rights of the software remain the property of Moser-Baer AG.

Designation	Description	Version	License	License Description (file)
U-Boot	Boot loader	2009.08	GPL version 2	COPYING
Linux	Operating system	3.2.0-rc3	GPL version 2	COPYING
Busybox	System environment	1.19.3	GPL version 2	LICENSE
NTP	NTP	4.2.8p12	Free	COPYRIGHT
Linux-ptp	PTP	2.0	GPL version 2	COPYING
pure-ftp	FTP server	1.0.35	Free, partly BSD	COPYING
NetSNMP	SNMP agent	5.8	BSD	COPYING
OpenSSL	SSL Lib.	1.1.1e	BSD style	LICENSE
OpenSSH	SFTP server	5.9p1	BSD	LICENCE
dropbear	SSH server	2018.76	MIT style:	LICENSE
			Free, party BSD	
wide-dhcpv6	DHCPv6 client	20080615	Free	COPYRIGHT
flex	Flex Lib.	2.5.35	BSD adapted	COPYING
zlib	Compress lib.	1.2.5	Free	README
mailsend	E-mail client	1.15b5	GPL	-

Existing software (OpenSource) with their own licences were partly used:

The complete license descriptions can be referred to in the file indicated in the respective original source code on the corresponding project page.

Licence text GPL, BSD and MIT:

GPL version 2: http://www.gnu.org/licenses/gpl-2.0.html

BSD: <u>http://www.opensource.org/licenses/bsd-license.php</u>

MIT <u>http://www.opensource.org/licenses/with-license.php</u>

The source code of the open source projects running under GPL can be requested from Moser-Baer AG (<u>support@mobatime.com</u>). Handling costs will be charged!

G Parameters

Group	Parameter	Acc	Default	Unit	SNMP
Network	2 * Network				dts4148Network (generally) dts4148Network1 (LAN 1) dts4148Network2 (LAN 2)
	DHCP on/off	RW	LAN 1: on LAN 2: off		dts4148DHCPMode
	IP address	RW	LAN 1: dhcp LAN 2: 192.168.1.5		dts4148IPAddr
	Network mask	RW	LAN 1: dhcp LAN 2: 255.255.255.0		dts4148IPMask
	Gateway IP	RW	LAN 1: dhcp LAN 2: 192.168.1.1		dts4148IPGateway
	Name server IP	RW	LAN 1: dhcp LAN 2:		dts4148IPNameserver
	Autoconf V6	RW	off		dts4148IPv6AutoConf
	DHCPv6	RW	off		dts4148IPv6DHCPMode
	IP address V6 1	RW	0::0		dts4148IPv6Addr1
	IP prefix 1	RW	64		dts4148IPv6Prefix1
	Gateway IPV6 1	RW	0::0		dts4148IPv6Gateway1
	IP address V6 2	RW	0::0		dts4148IPv6Addr2
	IP prefix 2	RW	64		dts4148IPv6Prefix2
	Gateway IPV6 2	RW	0::0		dts4148IPv6Gateway2
	Name server IPV6	RW	0::0		dts4148IPv6Nameserver
	Link 10/100Mbit	RW	auto		dts4148EthernetLinkMode
	Device name / Host name	RW	DTS4148		dts4148Hostname, dts4148NetInfoHostname
	Domain	RW			dts4148Domain
Network Services					dts4148NetServices
	Telnet	RW	on		dts4148TelnetMode
	SSH	RW	on		dts4148SSHMode
	FTP	RW	on		dts4148FTPMode
General					dts4148System
General	Display language	RW	engl.		dts4148Language
	Password user <i>dts</i>	RW	dts		dts4148Password
	Time zone operation and alarm messages	RW	MEZ		dts4148Timezone
	Redundant power supply	RW	off		dts4148PowerSupply
Lines					dts4148OutputLines
DCF out					dts4148OutMainDCF
	Mode	RW	on		dts4148OutMainDCFMode
	Time zone	RW	UTC		dts4148OutMainDCFTimezone
		1100			
NTP slave clocks					dts4148OutLineTZServer
	Mode	RW	off		dts4148OutLineTZServerMode
	Multicast IP	RW			dts4148OutLineTZServerMCastAddr
	Multicast Port	RW	65534		dts4148OutLineTZServerMCastPort
	Poll interval NTP	RW	0 → 1sec	2 ^x sec	dts4148OutLineTZServerNTPInterval
	Multicast TTL	RW	1		dts4148OutLineTZServerTTL
	Table interval	RW	60	sec	dts4148OutLineTZServerTableInterval
	Entry interval	RW	1	sec	dts4148OutLineTZServerEntryInterval
	Table time zone entries	RW	-1		dts4148OutLineTZServerTable (TZ entry number)
DCF / Pulse out					dts4148OutLineDCFPulseFREQ
	Mode (off, DCF, pulse)	RW	0		dts4148OutLineDCFMode
	Time zone	RW	UTC		dts4148OutLineDCFTimezone
	Pulse interval (every second, minute)	RW	sek		dts4148OutLineDCFPulseType
	Pulse time	RW	100	ms	dts4148OutLineDCFPulseTime
	Pulse period	RW	1	sec	dts4148OutLineDCFPulsePeriod
	Output correction	RW	0	ms	dts4148OutLineDCFPulseCorrection
	Frequency	RW	1000	Hz	dts4148OutLineDCFFrequency
IRIG / DCF- FSK-Out					dts4148OutLineIRIG
	1	- D14/			
	Mode (off, IRIG)	RW	0		dts4148OutLineIRIGIRIGMode

	Level	RW	2000	mV	dts4148OutLineIRIGOutputLevel
	Level bar	RW	200	mV	dts4148OutLineIRIGAlarmLevel
Serial out					dts4148OutLineSerial
	Mode (off, on)	RW	off		dts4148OutLineSerialMode
	Time zone	RW	UTC		dts4148OutLineSerialTimezone
	Telegram file	RW	MC482STD.TEL		dts4148OutLineSerialTeleFile
	Interface:	RW	h'45		dts4148OutLineSerialComParam
	Baud rate	RW	9600		
	Databit	RW	7		
	Stopbit	RW	1	-	
	Parity Com mode	RW	even		
	Commode	RW	out RS232		dts4148OutLineSerialComMode
E-mail					dts4148AlarmMailConfig
L-man	Mode	RW	Off		dts4148MailMode
	IP addr. mail server	RW			dts4148MailServerIPAddress
	Port mail server	RW	25		dts4148MailServerPort
	Receiver address 1	RW	20		dts4148MailAddrDestination1
	Receiver address 2	RW			dts4148MailAddrDestination2
	Sender address ("login to	RW			dts4148MailAddrFrom
	mail server")				
	Reply address	RW		1	dts4148MailAddrReply
	Error mask	RW	All set: FF FF FF FF FF FF FF FF		dts4148MailAlarmMask
	Auth. Mode	RW	off		dts4148MailAuthMode
	User name	RW		1	dts4148MailUser
	Password	RW			dts4148MailPassword
SNMP / - Traps					dts4148SnmpConfig
	Trap mode	RW	off		dts4148SnmpTrapMode
	Trap community	RW	trapmobatime		dts4148SnmpTrapCommunity
	IP addr. target computer 1	RW			dts4148SnmpTrapListenerIPAddress1
	Port target computer 1	RW	162		dts4148SnmpTrapListenerPort1
	Trap Version 1	RW	V2c		dts4148SnmpTrapVersion1
	IP addr. target computer 2	RW			dts4148SnmpTrapListenerIPAddress2
	Port target computer 2	RW	162		dts4148SnmpTrapListenerPort2
	Trap version 2	RW	V2c		dts4148SnmpTrapVersion2
	TRAP error mask	RW	All set: FF FF FF FF FF FF FF FF		dts4148SnmpTrapAlarmMask
	TO alive message	RW	off	sec	dts4148SnmpTrapAliveMsgInterval
	SNMP mode	RW	on		dts4148SnmpMode
	SNMP error mask	RW	All set: FF FF FF FF FF FF FF FF		dts4148SnmpAlarmMask
	Location	RW			dts4148SnmpLocation
	Contact	RW			dts4148SnmpContact
	rocommunity	RW	romobatime		dts4148SnmpROCommunity
	rwcommunity	RW	rwmobatime		dts4148SnmpRWCommunity
	2*Access config:		-		
	Password	RW			dts4148SnmpV3UserPasswordx
	UserSecLevel	RW	1+2: auth		dts4148SnmpV3UserLevelx
	UserRead	RW	1+2: all		dts4148SnmpV3UserRead x
	UserWrite	RW	1=dts1 2=dts2		dts4148SnmpV3UserWritex
	View1	RW	1+2:.1.3.6.1.4.1.8072		dts4148SnmpV3Viewx1
	View2	RW	1+2:.1.3.6.1.4.1.2021		dts4148SnmpV3Viewx2
	View3	RW	1+2:.1.3.6.1.4.1.13842.4		dts4148SnmpV3Viewx3
	View4	RW	1+2:.2		dts4148SnmpV3Viewx4
	View5	RW	1+2:.2		dts4148SnmpV3Viewx5
	View6	RW	1+2:.2		dts4148SnmpV3Viewx6
Alarm input/					dts4148RelayAlarmConfig
output:					
	Error mask relay	RW	All set: FF FF FF FF FF FF FF FF		dts4148RelayAlarmMask
	Mode alarm input	RW			dts4148AlarmInput
NTP / time					dts4148TimeHandling
handling					
Time source:					dts4148TimeSource
	Time source	RW	2 (GPS, DCF)		dts4148TSType
	Time zone	RW	0 (UTC)		
	Config. stratum	RW	0	Stratum	dts4148TSStratumMode
	Max. Time offset to set	RW	50ms	us	dts4148TSMaxOffsetForTimeValid

	system time OK				
	TO time source for error	RW	60	min	dts4148TSTimeout
	failure synch (TO)	11.00	00		
	Max. stratum for error	RW	12	Stratum	dts4148TSStratumErrorLimit
	failure synch (Stratum)				
	TO time source stratum	RW	24	h	dts4148TSStratumTimeout
	Offset change to	RW	50	ms / stratum	dts4148TSOffsetPerStratum
	decrement stratum by 1 Source correction (DCF		0		
	only)	RW	0	ms	dts4148TSDCFAdjustment
Catch-up:	Unity)				
outon up.	Catch-up mode	RW	1 (set)		dts4148TSAdjustmentMode
	Max. catch-up speed	RW	100ppm	ns / sec	dts4148TSMaxAdjustmentSpeed
	Core/Quartz type	RW	1		dts4148TSQuartzType
	Synch only offset	RW	0 (off)	ms	dts4148TSOffsetSynchOnly
	RTC Mode	RW	0 (off)		dts4148TSRTCMode
	Leap second mode	RW	0 (off)		dts4148TSLeapSecMode
	Leap second date next	RW			dts4148TSLeapSecDate
	correction				
Redundant					dts4148RedundantOp
operation:					
	Mode redundant operation	RW	off		dts4148RedOpMode
	Set manual master	RW			·
	Max. stratum master in red.	RW	16	Stratum	dts4148RedOpSwitchOverStratum
	operation	D 111	100		
	Max. time offset master to	RW	100ms	us	dts4148RedOpMaxOffsetSlaveTimeSource
	time source slave IP addr. 2. time server	RW			dts4148RedOp2ndDTSIPAddress
	Port DTS LAN link	RW	14338		dts4148RedOp2ndDTSIPAddress
	communication	11.00	14000		
NTP:					dts4148TimeNTPServer
	4 * NTP source				dts4148NTPSourceTable (14)
	Addresses	RW			dts4148NTPSourceAddr
	Minpoll	RW		2 ^x sec	dts4148NTPSourceMinPoll
	Maxpoll	RW		2 ^x sec	dts4148NTPSourceMaxPoll
	Mode Prefer (-red time source)	RW RW	server		dts4148NTPSourceMode dts4148NTPSourcePrefer
	Key	RW	normal off		dts4148NTPSourcePreter dts4148NTPSourceKey
	2 * Broadcast:		011		dis4140NTFSourceRey
	Broadcast address	RW			dts4148NTPBrodacstAddrx
	Interval	RW	2 → 4s	2 ^x sec	dts4148NTPBrodcastIntervalx
	Multicast TTL	RW	1		dts4148NTPBroadcastTTLx
	Кеу	RW	off		dts4148NTPBroadcastKeyx
	Trusted Keys	RW			dts4148NTPKeyTrusted
	Control Key	RW	0		dts4148NTPKeyControl
	Request Key	RW	0		dts4148NTPKeyRequest dts4148NTPAutokeyPassword
	Autokey Password	RW			dts4148NTPKeyGeneratorCmd
					dts4148NTPKeyFileCmd
PTP:					dts4148TimePTP
	Mode	RW	off		dts4148PTPMode
	Interface	RW	LAN1		dts4148PTPInterface
	Transport Protocol	RW	IPv4		dts4148PTPTranspProto
	IPv6 Scope	RW	h'E		dts4148PTPIPv6Scope
	Leap second offset	RW	100	-	dts4148PTPLeapOffset
	Priority 1 Priority 2	RW RW	128 128		dts4148PTPPriority1 dts4148PTPPriority2
	Domain	RW	0	+	dts4148PTPDomain
	Announce interval	RW	1	2 ^x sec	dts4148PTPAnnounceInterval
	Sync interval	RW	0	2^x sec	dts4148PTPSyncInterval
	Announce TO	RW	3	2^x sec	dts4148PTPAnnounceTO
	Delay mechanism	RW	E2E		dts4148PTPDelayMechanism
Manual					dts4148TimeManualSet
There is a second secon		1			
Time set	Timo	14/			
Time set	Time Diff	W		ms	dts4148ManualTimeSetUTC
Time set	Time Diff	W W		ms	dts4148ManualTimeSetDiff
Time set Product Info				ms	
				ms	dts4148ManualTimeSetDiff
	Diff	W		ms	dts4148ManualTimeSetDiff dts4148ProdInfo

	1.847		1	
	HW code	R		dts4148ProdInfoHWCode
	HW name	R		dts4148ProdInfoHWName
Custom Info	Firmware version	R		dts4148ProdInfoFirmwareVer
System Info	DTS state	B		dta 4149 Cua Statua
	DTS state DTS alarms	R R		dts4148SysStatus dts4148SysAlarms
	Alarm relay state	R		uls41465ysAlamis
	SNMP alarms (masked)	R		
Trap Info	Sinivip alaritis (masked)	R		
Парішо	Trop state	R		
	Trap state Trap alarm number			
	Trap error state	R		
	Trap time	R R		
	Trap message	R		
Time Info	Trap message	R		dto 11 10 System Time Info
Time into	DTS stratum	P		dts4148SystemTimeInfo dts4148TinfoStratum, dts4148SysStratum
	Last drift	R		dts4148TinfoLastDrift, dts4148SysLastDrift
	Last quartz corr	R		dts4148TInfoLastQCorr
	Act. corr. voltage	R		dts4148VoltageQuartzAdjust
	Current offset sec	R		dts4148DCFTInfoOffsetSec
			sec	
	Current offset us	R	us	dts4148DCFTInfoOffsetUSec, dts4148SysOffset
	Time of last time info	R	1	dts4148SysOffset dts4148TInfoLastTime
	Jitter	R	1	dts4148TInfoSourceJitter
	Source quality	R	1	dts4148SysTimeReceptionQuality
	Offset of local source	R	1	
	Sample type	R	1	
	Sample type Source Type	R	1	dts4148SysTimeSource
	Last DCF time	R	1	dts41485ys11meSource dts4148DCFTInfoLastTime
	Last DCF time	R	1	dts4148DCFTInfoLastLinkTime
	DCF pulse counter	R	1	dts4148DCFTInfoSecCount
	Link pulse counter	R	1	dts4148DCFTInfoLinkSecCount
	Red. State	R	1	dts4148DCFTInioLinkSecCount dts4148SysMasterMode
	NTP source	R	1	dts4148SysMasterMode dts4148NTPTInfoCurrentSource
	NTP offset	R		dts4148NTPTInfoSystemOffset
	NTP Jitter	R		dts4148NTPTInfoSourceJitter
	NTP Stratum	R		dts4148NTPTInfoStratum
	NTP Frequency	R		dts4148NTPTInfoFrequency
Versions		n		dts4148SystemVersions
Ver310113	Version DTS application	R		dts4148verApplication
	Version DTS module	R		dts4148verTimeDriver
	Version FPGA module	R		dts4148verFPGADriver
	Version FPGA	R		dts4148verFPGA
	Version NTP	R		dts4148verNTP
	Version kernel	R		dts4148verLinux
	Version busybox (CLI)	R		dts4148verCLIShell
	Version rootfs	R		dts4148verRootFS
	Version language	R		dts4148verLangResource
	Version TZ table	R	1	dts4148verTimezoneTable
	Version snmp master	R	1	dts4148verSNMPMasterAgent
	Version snmp common	R	1	dts4148verSNMPSubAgent
			1	
Power Info		+ +	1	dts4148SystemPower
	Voltage 1	R	V	
	Voltage 1	R	mv	dts4148SupplyVoltage1
	Voltage 2	R	V	
	Voltage 2	R	mv	dts4148SupplyVoltage2
	Current 1	R	A	
	Current 1	R	mA	dts4148SupplyCurrent1
	Current 2	R	A	
	Current 2	R	mA	dts4148SupplyCurrent2
2*Network				dts4148NetworkInfox
Info				
	IP v4	R	1	dts4148NetInfoxIPAddr
	GW v4	R	1	dts4148NetInfoxIPGateway
	Subnet v4	R	1	dts4148NetInfoxIPMask
	DNS v4	R	1	dts4148NetInfoxIPMask dts4148NetInfoxIPNameserver
L	Hostname	R	1	
	Domain	R	1	dts4148NetInfoxDomain
				dts4148NetInfoxDomain dts4148NetInfoxDHCPMode
		R		
	DHCP	R		
	DHCP Link	R		dts4148NetInfoxEthernetLinkMode
	DHCP Link IP v6 link local	R R		dts4148NetInfoxEthernetLinkMode dts4148NetInfoxIPv6AddrLocal
	DHCP Link IP v6 link local IP1 v6	R R R		dts4148NetInfoxEthernetLinkMode dts4148NetInfoxIPv6AddrLocal dts4148NetInfoxIPv6Addr1
	DHCP Link IP v6 link local	R R		dts4148NetInfoxEthernetLinkMode dts4148NetInfoxIPv6AddrLocal

Commands			dts4148SystemMaintenance
	Update cmd.	W	dts4148SysUpdateCmd
	Backup cmd.	W	dts4148SysBackupCmd
	Restore cmd	W	dts4148SysRestoreCmd
	Restore default cmd	W	dts4148SysDefaultCmd
	Restart cmd	W	dts4148SysRestartCmd
	Copy files cmd	W	dts4148SysCopyFiles
	Set all config changed	W	dts4148SysAllChanged

H Technical data

Dimensions	19" Rack, 1HU x 28PU (H x W x D [mm]) = 483 x 44 x 125				
Weight	approx. 1.8 kg				
Ambient temperature	0 to 60° C, 10-90% relative humidity, without condensation				
Operation	Telnet / SSH / MOBA-NMS (via LAN). In addition, operation is also possible with SNMP.				
Accuracy	GPS (DCF input) to NTP server:typical < +/- 100 μ sGPS (DCF input) to PTP server:typisch < +/- 10 μ sPTP master to PTP slavetypisch < +/- 100 ns				
Notice:	NTP reception (DTS 4148 as client or as server to external clients) can be influenced by the network traffic load and network devices (Hub, Switch, Router, Firewall). If many clients request simultaneously, the typical accuracy may not be reached.				
Time keeping (internal)	Synchronized with GPS: +/-10 μs to UTC				
Holdover (free run): DTS 4148 -> OCXC	After at least 12 hours synchronization from the time source: at 20°C +/- 5°C: < +/- 1 ms / day (< 0.01ppm) *				
Generally:	During power break (based on internal RTC): at 20°C +/- 5°C: < 5 ppm, but with jitter of +/- 15 ms * After a power failure the RTC time is available during at least 5 days (RTC buffered through a SuperCAP).				
	*measured over 24 h				
Redundant operation	- Master to slave (optical DTS link): typical < +/- 1 μ s				
Time server	NTP V4(fully V3 compatible), RFC 1305, RFC 5905 (Port 123)SNTP(UDP), RFC 2030 (Port 123)PTP(UDP), IEEE 1588-2008 (V2) (Ports 319 and 320)TIME(TCP/UDP), RFC 868 (Port 37)DAYTIME(TCP/UDP), RFC 867 (Port 13)Max. number of NTP and SNTP client requests: > 1500 requests / sec.(e.g. client request every 60 sec. $rightarrow$ 90000 clients)				
NTP mode	Server, Peer, Broadcast, Multicast				
NTP slave clock lines:	 line with up to 15 different time zone entries. Communication through multicast: -RFC 3376: Internet Group Management Protocol, Version 3 -RFC 1112: Host extensions for IP multicasting -RFC 4601: Protocol Independent Multicast - Sparse Mode (PIM-SM) -RFC 3973: Protocol Independent Multicast - Dense Mode (PIM-DM) 				
Time zones (see App. B)	Up to 80 predefined, 20 programmable entries (MOBA-NMS)				
PTP	-Standard: IEEE 1588-2008 (V2, no V1) -P2P, E2E -IPv4, IPv6, Layer2, UDP, multicast according to definition IEEE 1588 -Master only (active or passive) -"2 step" procedure only: synch. message with follow-up message -availability of management messages limited: requests only				

	-profile: IEEE 15 -no specific PTF	588 annex J, Default and U 9 SNMP MIB	tility profile
2 Network interfaces	10BaseT / 100BaseTX (IEEE 802.3) Data transmission rate: Auto-negotiation / manual Connection: RJ-45 Only shielded cables permitted.		
IP Configuration	DHCP, Static IP	, IPv4, IPv6	
Network services	NTP SNTP PTP TIME DAYTIME Telnet SSH SCP SFTP FTP SNMP SMTP DHCP DNS DHCPv6 ECHO	UDP, Port 123 UDP, Port 123 UDP, Port 319 and 320 TCP/UDP, Port 37 TCP/UDP, Port 13 TCP, Port 23 TCP, Port 22 über SSH über SSH TCP, Port 21 UDP, Port 161 UDP, Port selectable (16 TCP, Port selectable (25) UDP, Port 68 TCP/UDP, Port 53 only IPV6 ICMP	see timeserver see timeserver see timeserver see timeserver operation operation update update update operation 2) alarm notification, see SNMP alarm mail see E-Mail dyn. address allocation (client) address resolution (client)
SNMP		-	nd DES for encryption (privacy).
E-mail		t the mail server: - with sender address	d SMTP-Auth with LOGIN, RAM-MD5 (RFC 2195)
DCF input	DCF receiver or DCF from GPS, active current loop Time zone: selectable Nominal 28 VDC, max. 32mA, response threshold 8mA		
AFNOR-A/C, IRIG-B12x input: Upp: 100mV – 5500mV			
Time signal outputs	 NTP V4 for slave clocks (unicast and multicast) 1 x IRIG-B output (analog and digital) 1 x DCF, programmable impulse / frequency output over RS 422 and opto coupler (current loop passive) 1 x DCF current loop interface passive 1 x Script files configurable time telegrams on RS 232, RS 422 (only send) and RS 485 		
DCF output (1x)	Max. time deviat DCF time code	time zone selectable tion with GPS source: passive current interface: /DC, I _{on} = 1015 am, I _{off} < 0	+/- 10 μs, jitter < 10 μs).1 mA @20VDC
DCF impulse / frequency output (1x)	Max. time deviat Mode: - DCF time c - impulses: s	table, output signal correct tion with GPS source: ode ec., min., h., or user-define	

	2 different electrical outpu - passive current loop - RS422	uts with the same signal: output, opto coupler: I _{max.}	=10 mA / U _{max.} =50 VDC
IRIG-B output (1x)	1 high precision IRIG line, available as analog and digital signals. Max. time deviation to GPS (with GPS source): DC level: $< +/- 10 \ \mu s$ Modulated: $< +/- 200 \ \mu s$		digital signals.
	Accuracy of the signal ac DC level pulse rise time k 10 and 90% amplitude po Jitter modulated at carrie DC level jitter pulse-to-pu	between the bints: r frequency:	≤ 1 μs ≤ 1% ≤ 200 ns
	IRIG-B126,	IRIG-B Std 12h (Bx22), IF IRIG-B DIEM, AFNOR A, IRIG-B003, IRIG-B006	
	Output voltage level (R _L =50 Ohm): SNR _{IdB} : Impedance: Opto coupler outputs: RS422 outputs:	0.1 - 5.5 Vpp (configur typical >= 40dB Ri < 50 Ω I _{max.} =10 mA / U _{max.} =50 V U = typical 3.3 VDC	
Serial interface (1x) (back side)	1 line for telegram output RS232, RS422 or RS485 Max. time deviation to internal time: +/- 10 ms, Jitter < 10 ms 300-38400 Bauds, 7 or 8 Data bits, Parity: no, even, odd, Stop bit: 1 or 2, no flow control) The description of the telegram function is provided in Appendix E.		
USB plug	USB host for USB stick		
Alarm contact	Opening relay contact (A Breaking capacity:	larm active → contact ope max. 30 W (DC) or 60 V max. 60 VDC or 1 A / 30	A (AC)
Alarm reporting / Error reporting	Alarm contact E-mail SNMP notification Display Alarm-LED	see Alarm contact see E-mail see SNMP trap see Display -	
Alarm input	18-36 VDC, max. 6mA, fo Function configurable	or external closing contact	
DTS Link	 Plug-in position for mini GBIC module (GigaBit Interface Converter) 1000Mbps, 3,3V (with LC connector) e.g. D-Link DEM-311GT, SX 850 nm, 1.25 Gbps/MM/3.3 V Maximal cable length depends on type of cable: Multimode fiber with a diameter of 50 μm: max. 550 m Multimode fiber with a diameter of 62.5 μm: max. 275 m With LX standard, longer cables can be achieved. 		
Display	2 lines with up to 16 char	acters for the display of st	atus information.
DC power supply	24 VDC +20% / -10% / max. 15 W		
Power supply output	DC in voltage -2 V, max.	400 mA	

2

2 LAN Mode 34, 70

A

Accuracy Alarm Alarm configuration Alarm input Alarm list Alarm mask Alarm relay Alarm status Authentication Autoconf – Ipv6	100 46 41 46, 102 85 42 42, 102 14 44, 66 50 67
Autokey	67

B

Baudrate	27
Boot time	15
Broadcast NTP	37

С

Community (SNMP)	71
Configuration	24
Configuration – Backup	56
Configuration – Restore	56
Configuration – save	61
Connection table (to fill in)	105
Connections – alarm relay	77
Connections – DCF & GPS	79
Connections – front view	76
Connections – IRIG-B12x input	77
Connections – IRIG-B12x outputs	77
Connections – rear view	77
Connectors	79
Control Key	38
Copyright	94
CRAM-MD5	44

D

Data bit Daylight Saving Time DAYTIME DC power supply DCF – connection DCF input DCF output Default values DES – Data Encryption Standar DHCP DHCPv6 Display DST DTS (Distributed Time System)	49 50 14 83 10
DTS (Distributed Time System) DTS Link	10 34, 69, 77, 78, 102

Ε

E-mail

F

Factory settings Firmware Front connections FTP	15, 56, 95 14 76 50, 60, 101
G	
GBIC GBIC Module GNSS 3000 GPS 4500	77, 78, 102 69 79 79
I	
IEEE 1588 Initial configuration Interface IPv4 configuration IPv6 – FTP connection IPv6 configuration	40, 68, 100 15 89 49 60 50
Κ	
Кеу	66
L	
Language setting Leap second Leap second mode LED description front side LED description rear side Lines Linux Login (menu)	47 66 39 13 13 25 16 16
М	
Maintenance Manual time set MD5 Menu login Menu structure MIB files mini GBIC MOBA-NMS Multicast Multicast address Multicast NTP	56 39, 64 66 16 17 71 69, 77, 78, 102 10, 16, 18, 57, 101 30, 100 35 37
Ν	
Network configuration Network services Notification NTP NTP as backup time source NTP authentication NTP Autokey NTP broadcast NTP mode NTP multicast	48 50, 100, 101 72 101 35, 65 38, 66 67 37 100 37

43, 101

NTP server	35
NTP slave clocks	30, 100
NTP symmetric keys	66
NTP time source	23, 36
NTP version	65
ntp.keys	38
ntpq	21

0

Operation (menu)	16
Operation (MOBA-NMS)	18
Operation (SNMP)	72

Ρ

Parameters	95
Parity	27
Password	7, 16
Password configuration	47
Power setting	47
Power supply	75
Problem solving	87
Program file	62
PTP	40, 68, 70, 100

R

Redundant NTP Multicast time server	31
Redundant operation	34, 69
Request Key	38
Restart	15, 56
RTC	100
RTC (Real Time Clock)	63
RTC mode	33

S

Schaltsekunde SCP	40 61, 101
Script file definition	90
Season table	80
Security - network	7
Serial telegrams	27, 89
SFTP	60, 101
SMTP	101
SNMP	11, 71, 101
SNMP – alarm notification	74
SNMP – alive notification	74
SNMP – notification	72
SNMP – operation	72
SNMP access configuration	54
SNMP configuration	45, 51

SNMP traps SNMP user configuration SNTP Software update Software version Spring terminals SSH Standard settings Start-up Status menu Stop bit Stratum T	45, 72 53 101 57, 58 14 79 17, 50, 101 15, 95 15 20 27 64
TAI Telegram – definition Telegram file Telnet Terminal TIME Time acceptance Time administration Time server Time source – configuration Time source – time acceptance Time zone Time zone for displayed time Time zone selection Time zone selection Time zone server Time zone table Time-keeping Transmission time Trap Troubleshooting Trusted Key ttl (time to live)	$\begin{array}{c} 40\\ 90\\ 27, 56, 62, 89\\ 16, 50, 101\\ 16\\ 101\\ 64\\ 31, 63, 64\\ 65, 100\\ 32\\ 64\\ 80\\ 47\\ 55\\ 30\\ 80\\ 33, 64\\ 89\\ 45, 72\\ 87\\ 38\\ 37\end{array}$
U Update – software Update time zone table USB USB stick UTC V	57, 58 84 56, 58, 59, 62 14, 15 63, 83

Version 14 W World time 30

J Connection table (to fill in)

Туре	Description
	Type

Example:

Line	Туре	Description
DCF	DCF out	DCF for master clock ETC1



HEADQUARTERS / PRODUCTION

MOSER-BAER AG Spitalstrasse 7, CH-3454 Sumiswald Tel. +41 34 432 46 46 / Fax +41 34 432 46 99 moserbaer@mobatime.com / www.mobatime.com

SALES SWITZERLAND

MOBATIME AG Stettbachstrasse 5, CH-8600 Dübendorf Tel. +41 44 802 75 75 / Fax +41 44 802 75 65 info-d@mobatime.ch / www.mobatime.ch

SALES GERMANY, AUSTRIA

BÜRK MOBATIME GmbH Postfach 3760, D-78026 VS-Schwenningen Steinkirchring 46, D-78056 VS-Schwenningen Tel. +49 7720 8535 0 / Fax +49 7720 8535 11 buerk@buerk-mobatime.de / www.buerk-mobatime.de

SALES WORLDWIDE

MOSER-BAER SA EXPORT DIVISION 19 ch. du Champ-des-Filles, CH-1228 Plan-les-Ouates Tel. +41 22 884 96 11 / Fax + 41 22 884 96 90 export@mobatime.com / www.mobatime.com

MOBATIME SA En Budron H 20, CH-1052 Le Mont-sur-Lausanne Tél. +41 21 654 33 50 / Fax +41 21 654 33 69 info-f@mobatime.ch / www.mobatime.ch

